


# PVM-2130QM

## RM-668

## SERVICE MANUAL



*AEP Model*  
Chassis No. SCC-A99A-A  
*Australian Model*  
Chassis No. SCC-B22A-A  
*West Germany Model*  
Chassis No. SCC-B19A-A

### SPECIFICATIONS

**Note:** The service manuals for RM-668 have been issued separately.

Color system	PAL, SECAM, NTSC and NTSC <sub>4.43</sub> systems, switched automatically	LINE A/B outputs (loop-through outputs)	VIDEO: BNC connector
Picture tube	Trinitron tube Approx. 54.5 cm (21 inches) (50.6 cm picture measured diagonally) 100-degree deflection, AG pitch 0.55 mm	AUDIO: Phono jack	
Resolution	Video input: 420 TV lines RGB inputs: 640 × 200 dots (2000 characters)	Monitor outputs	VIDEO: BNC connector Composite video, 1 Vp-p AUDIO: Phono jack Less than 1 kilohm
Color temperature	9300°K	Digital RGB inputs	RGB: D-sub 9-pin connector (See "Signal assignment".) AUDIO: Phono jack -5 dBs, more than 47 kilohms
Frequency response	10 MHz (-3 dB, RGB) 5 MHz (-3 dB, composite video)	AV connector	21-pin connector (See "Signal assignment".)
Horizontal linearity	Less than ±7%	Speaker terminals	8 ohms
Vertical linearity	Less than ±8%	Control S input/output	Minijack, 5 Vp-p
Line pull range	Horizontal: +500 Hz Vertical: -8 Hz	Power output	7 W + 7 W at 8 ohms
Overscan of the picture	Less than +7%	Power requirements	220 - 240 V AC, 50/60 Hz
Convergence	Central area: within 1.0 mm Periphery: within 1.8 mm	Power consumption	140 W
LINE A/B, VTR inputs		Dimensions	Approx. 516 × 409 × 482 mm (w/h/d) incl. projecting parts and controls
VIDEO IN:	LINE A/B: BNC connector Composite video, 1 Vp-p ±6 dB, sync negative, 75-ohm termination switchable	Weight	Approx. 30.6 kg
	VTR: 8-pin connector Composite video, 1 Vp-p ±6 dB, sync negative, 75-ohm terminated	Supplied accessory	Remote commander RM-668, with 2 R6 batteries..... 1
AUDIO IN:	LINE A/B: Phono jack -5 dBs, more than 47 kilohms VTR: 8-pin connector, -5 dBs, more than 47 kilohms	Optional accessories	TV stand SU-538, SU540 Speaker system SS-X6A, APM-X5A

— Continued on page 2 —




# TRINITRON COLOR VIDEO MONITOR

# SONY®

MON

## SIGNAL ASSIGNMENT


### DIGITAL RGB connector (D-sub 9-pin)



Digital signal (TTL level)

Pin No.	Signal assignment
1	Ground
2	Ground
3	Red input
4	Green input
5	Blue input
6	Intensity input
7	No connection
8	H. sync input (positive/negative)
9	V. sync input (positive/negative)

### AV connector (21-pin)



Pin No.	Signal	Signal level
1	Audio output B (right)	Standard level: 0.5 Vrms Output impedance: Less than 1 k ohm *
2	Audio input B (right)	Standard level: 0.5 Vrms Input impedance: More than 10 k ohms *
3	Audio output A (left)	Standard level: 0.5 Vrms Output impedance: Less than 1 k ohm *
4	Ground (audio)	
5	Ground (blue)	
6	Audio input A (left)	Standard level: 0.5 Vrms Input impedance: More than 10 k ohms *
7	Blue input	0.7 V $\pm$ 3 dB, 75 ohms, positive
8	Function select (AV control)	High state (9.5 – 12 V): Peri mode Low state (0 – 2 V): TV mode Input impedance: More than 10 k ohms Input capacitance: Less than 2 nF

Pin No.	Signal	Signal level
9	Ground (green)	
10	Open	
11	Green input	(Same as Pin 7)
12	Open	
13	Ground (red)	
14	Ground (blanking)	
15	Red input	(Same as Pin 7)
16	Blanking input	High state (1 – 3 V) Low state (0 – 0.4 V) Input impedance: 75 ohms
17	Ground (video output)	
18	Ground (video input)	
19	Video output	1 V $\pm$ 3 dB, 75 ohms, positive Sync: 0.3 V ( $\pm$ 3 dB)
20	Video input	1 V $\pm$ 3 dB, 75 ohms, positive Sync: 0.3 V ( $\pm$ 3 dB)
21	Common ground (plug, shield)	

\* at 20 Hz – 20 kHz

Design and specifications subject to change without notice.

## TROUBLESHOOTING

If these symptoms occur when you begin operation, follow the suggestions below.


SYMPTOMS	CORRECTIONS
No controllable keys although the POWER switch is turned on.	• Press the CONTROL key.
No indication appears although the CONTROL key is pressed.	• Set the MANUAL CONTROL switch on the rear panel to ON.
Remote control is not possible.	• Set the REMOTE CONTROL switch on the rear panel to ON.

If the problem still cannot be solved, contract your authorized Sony dealer.

## TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>
<b>1. GENERAL</b>		
1-1.	Location and Function of Parts and Control . . . . .	4
1-2.	Operation . . . . .	8
1-3.	System Connections. . . . .	9
<b>2. DISASSEMBLY</b>		
2-1.	Power Block Assy and Chassis Assy Removal . . . . .	13
2-2.	Key Board Unit Removal . . . . .	13
2-3.	Picture Tube Removal . . . . .	14
<b>3. SETUP ADJUSTMENTS</b>		
3-1.	Beam Landing. . . . .	15
3-2.	Covergence. . . . .	16
3-3.	White Balance Adjustment . . . . .	18
<b>4. CIRCUIT ADJUSTMENTS</b>		
4-1.	FA Boards Adjustment. . . . .	19
4-2.	D Boards Adjustment. . . . .	19
4-3.	HC Board Adjustment . . . . .	20
4-4.	B Board Adjustment . . . . .	20
4-5.	Safety Check Adjustment . . . . .	21
<b>5. DIAGRAM</b>		
5-1.	Circuit Boards Location . . . . .	23
5-2.	Block Diagram . . . . .	24
5-3.	Frame Schematic Diagram. . . . .	29
5-4.	Schematic Diagram and Printed Wiring Boards. . . . .	34
5-5.	Semiconductors . . . . .	63
<b>6. EXPLODED VIEWS</b>		
6-1.	Picture Tube. . . . .	65
6-2.	Chassis . . . . .	66
6-3.	Back Cover. . . . .	67
6-4.	Key Board Unit . . . . .	68
<b>7. ELECTRICAL PARTS LIST</b>		69


### SAFETY-RELATED COMPONENT WARNING !!

COMPONENTS IDENTIFIED BY SHADING AND MARK  ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL TO SAFE OPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.

## SECTION 1 GENERAL

### 1-1. LOCATION AND FUNCTION OF PARTS AND CONTROL

#### FRONT PANEL



• Press CONTROL key after power is turned on to illuminate the control keys or indicators.

The following control keys are effective only when MANUAL CONTROL switch on the rear panel is set to ON.



**[1] NORM (normal) key**

Press this key to return to the standard setting.

- This key is effective only for the control keys on the left.

**[2] HUE control keys**

Press the GRN (green) key to make the skin tones greenish or the PUR (purple) key to make it purplish.

- These control keys are effective for the NTSC and NTSC<sub>4.43</sub> color systems only.

**[3] COLOR control keys**

Press the + key to make the color intensity vivid or the – key to make it pale.

**[4] BRIGHT (brightness) control keys**

Press the + key to make the picture brighter or the – key to make it darker.

**[5] SHARP (sharpness) control keys**

Press the + key to obtain a sharp picture or the – key to obtain a soft picture.

**[6] BALANCE control keys**

Press the L key to increase the sound volume of the left speaker or the R key to increase the sound volume of the right speaker.

**[7] Color system indicators**

**PAL, SECAM, NTSC, NTSC<sub>4.43</sub>**

The color system of the input signal is automatically selected and the corresponding indicator illuminates. When the input signal is monochrome, no color system indicator illuminates.

**[8] MUTING indicator**

Illuminates while the sound is muted.

- Muting is controlled only by the Remote Commander.

**[9] STANDBY indicator**

Illuminates when the power is turned off by the Remote Commander.

**[10] POWER switch**

Press this switch to turn the monitor on.

Press this switch again to turn it off.

- When the monitor is turned on, the settings of the monitor are the same as when it was last turned off.
- For a few seconds after turning on the monitor the color of picture may vary because the white balance is adjusted at this time. This is not a problem.

**[11] Remote control detector**

The beam from the Remote Commander is received here.

**[12] CONTROL key**

Press this key to illuminate the keys and indicators on the front panel.

Press this key again to extinguish them.

**[13] VOLUME control keys**

Press the + key to raise the volume or the – key to lower it.

**[14] PICTURE control keys**

Press the + key to make the contrast, color intensity and brightness stronger or the – key to make them weaker.

**[15] Input select keys**

**LINE A, LINE B, VTR, AV, DIGITAL**

Select the input source connected to the LINE A, LINE B, VTR, AV or DIGITAL RGB connector.

When a key is pressed:


- it blinks if the other indicators and keys on the front panel illuminate.
- it illuminates if they are extinguished.

**Key illumination**

For the keys [1] through [7], [13] and [14]:

- While each key is pressed, it blinks, indicating that adjustment is going on.
- During adjustment, if the adjustment value reaches the limit, the blinking speed becomes slower.

## REAR PANEL



### 1 TREBLE control

Turn clockwise for more treble (high tone), or counterclockwise for less.

### 2 BASS control

Turn clockwise for more bass (low tone), or counterclockwise for less.

### 3 PICTURE (RGB) control

Adjust the contrast of the RGB signals connected to the AV connector or the DIGITAL RGB connector.

### 4 H CENTER (DIGITAL RGB) (horizontal centering) control

When the picture of DIGITAL RGB input is decentered horizontally, correct it with this control.

### 5 V HOLD (vertical hold) control

When the picture rolls vertically, correct it with this control.

### 6 CONTROL select switches

Normally set to ON.


#### REMOTE CONTROL switch

Set this switch to ON to control the monitor with a Remote Commander.  
If this switch is set to OFF, the remote control is not possible.

#### MANUAL CONTROL switch

Set this switch to ON to control the monitor manually.  
To make the manual control of the control keys or switches on the front panel impossible, extinguish the indicators by pressing the CONTROL key on the front panel and set this switch to OFF.  
(However remote control is possible if the REMOTE CONTROL switch is set to ON.)

## CONNECTORS



### 1 SPEAKER L/R terminals

Connect to speakers with 8 to 16 ohm impedance.

### 2 CONTROL S IN/OUT connectors

Connect to the CONTROL S connectors of a VTR or another monitor.  
It is then possible to control the whole system with a single Remote Commander.

### 3 LINE A/LINE B inputs

**VIDEO IN connector (BNC type)**

**AUDIO L/R IN jacks (phono jack)**

Connect to the video and audio outputs of a VTR or a camera.

**VIDEO OUT connector (BNC type)**

**AUDIO L/R OUT jacks (phono jack)**

Loop-through outputs of the IN connector and jacks.

Connect to the video and audio inputs of another monitor.

### 75-ohm termination switch

When only the VIDEO IN connector is used (nothing is connected to the VIDEO OUT connector), set this switch to ON.

When both connectors are used together for a loop-through connection, set this switch to OFF.

### 4 MONITOR OUT connectors

**VIDEO connector (BNC type)**

**AUDIO L/R jacks (phono jacks)**

The video and audio signals supplied from the LINE A, LINE B, VTR or AV input selected by the front panel input select keys are output from these connectors.

Connect to the video and audio inputs of another monitor, VTR, etc.

### 5 VTR connector (8-pin)

Connect to a VTR with an 8-pin TV connector.

### 6 DIGITAL AUDIO jack (phono jack)

Connect to the audio output of an audio source to listen to the sound from the connected audio source while viewing the picture from the DIGITAL RGB connector.

### 7 DIGITAL RGB connector (9-pin, D-sub)

Connect to the digital RGB output of a microcomputer.

### 8 INTENSITY switch

Normally set to OFF. When a microcomputer provided with intensity output is connected, set to ON for 16-color display.

### 9 AV switch

Set to ON so that the monitor is automatically switched to the AV input when a signal is input from the AV connector, taking priority over the LINE A, LINE B or VTR input previously selected by the input select keys on the front panel. Set to OFF to select the AV input manually by pressing the AV input select key.

### 10 SUPERIMPOSE switch

Normally set to ON.


Set to OFF to display the analog RGB signal from the microcomputer connected to the AV connector.

### 11 AV connector (21-pin)

Connect to the 21-pin multiconnector of an 8 mm video cassette recorder or the analog RGB multioutput connector of a microcomputer.

## 1-2. OPERATION

### DISPLAYING THE PICTURE



- 1** Depress the POWER switch.  
One of the input select keys illuminates.
- 2** Press the CONTROL key.  
The selected input select key blinks and all control keys on the front illuminate.  
(If the control keys do not appear, set the MANUAL CONTROL switch on the rear to ON.)
- 3** Press the desired input select key.  
The pressed key blinks and the picture from the selected input is displayed on the screen and the sound is heard through the speakers.  
(For selecting the AV or DIGITAL input, see "Notes on input selection".)
- 4** Adjust the picture and sound.
- 5** Press the CONTROL key to extinguish the controls keys so that only the selected input select key illuminates.

### SUPERIMPOSING

To superimpose the data from the microcomputer connected to the AV connector over the picture, proceed as follows. (The data should be processed for superimposition on the microcomputer.)

- 1** Set the SUPERIMPOSE switch to ON.
- 2** Press the LINE A, LINE B or VTR input select key to display the picture on which the data is to be superimposed on the monitor screen.
- 3** Press the AV input select key.  
The data is superimposed over the picture.
- 4** Adjust the contrast of the superimposed data with the PICTURE (RGB) control.

### NOTES ON INPUT SELECTION

#### AV input and SUPERIMPOSE switch

Set the SUPERIMPOSE switch on the rear as follows, according to the signal supplied to the AV connector.

SUPERIMPOSE switch	Signal to be displayed
ON	<ul style="list-style-type: none"> <li>To display the composite video signal from an 8 mm video cassette recorder, etc.</li> <li>To perform superimposition. (See "SUPERIMPOSING".)</li> </ul>
OFF	<ul style="list-style-type: none"> <li>To display the analog RGB signal from a microcomputer, etc. In this case, the sync signal should be supplied to pin 20 of the AV connector.</li> </ul>

- When the AV input select key is pressed with the SUPERIMPOSE switch ON, the previously selected LINE A, LINE B or VTR input select key blinks together with the AV key.
- When it is pressed with the SUPERIMPOSE switch OFF, only the AV key blinks.

#### AV input and AV switch

When the AV switch on the rear is set to ON, the monitor is automatically switched from the LINE A, LINE B or VTR input to the AV input if a signal is input to the AV connector. Set the AV switch to OFF to select the AV input manually by pressing the AV input select key.

#### DIGITAL input


- To display the digital RGB signal from a microcomputer provided with intensity output in 16 colors, set the INTENSITY switch on the rear to ON.
- If necessary, center the picture from the DIGITAL RGB connector with the H CENTER control on the rear panel.

#### Note

The COLOR, HUE and SHARP control keys do not function when the DIGITAL input is selected or the AV input is selected with the SUPERIMPOSE switch OFF.

### 1-3. SYSTEM CONNECTIONS

#### CONNECTION DIAGRAM




#### Note

- When a microcomputer has an analog RGB output connector, connect it to the AV connector.
- When a microcomputer has only a composite video output connector, connect it to the LINE A or LINE B VIDEO IN connector.

## CONNECTING SEVERAL MONITORS


A loop-through connection is convenient for monitoring the same signal on their monitors. Up to 10 monitors can be connected. It is recommended to use a signal distributor when several monitors are connected.




## CONTROL S CONNECTION

The following connections allow remote control of several monitors and a VTR through a single monitor.

### Example 1




### Example 2




**Note**

Do not use the following loop connections.

**Example 1**



**Example 2**




 CONTROL S signal flow




## SECTION 2 DISASSEMBLY


### 2-1. POWER BLOCK ASSY AND CHASSIS ASSY REMOVAL




### 2-2. KEY BOARD UNIT REMOVAL




## 2-3. PICTURE TUBE REMOVAL




### • Removing Procedures



- ① Turn up one side of the rubber cap in the direction indicated by the arrow (a)



- ② Using a thumb, pull up the rubber cap firmly in the direction indicated by the arrow (b)



- ③ When one side of the rubber cap is separated from the anode button, the anode cap can be removed by turning up the rubber cap and pulling it in the direction of the arrow (c)

## SECTION 3

### SET-UP ADJUSTMENTS

- The following adjustments should be made when a complete realignment is required or a new picture tube is installed.
- These adjustments should be performed with rated power supply voltage unless otherwise noted.

Perform the adjustments in order as follows:

1. Beam Landing
2. Convergence
3. White Balance

**Note:** Test Equipment Required

1. Color-bar/Pattern Generator
2. Degausser

#### 3-1. BEAM LANDING

Preparation:

- Input the RASTER pattern.
  - Before starting, degauss the entire screen.
1. Turn on set power supply and input a RASTER signal.
  2. Evenly degauss the entire screen.
  3. Loosen the deflection yoke mounting screw, and set the purity control to the center as shown in Figure 3-1.
  4. Input a red signal.
  5. Move the deflection yoke back, and adjust the purity control so that RED is in the center and GREEN and BLUE are at the sides, evenly. (Figure 3-2.)
  6. Move the deflection yoke forward so that the entire screen is red.
    - If the deflection yoke is pushed all the way to the CRT then moved slightly back, landing adjustment is easier.
  7. Substitute GREEN, then BLUE for RED in step 4 and check landing.
  8. Rotate RED, GREEN and BLUE once each and check landing.
  9. When landing is not right, adjust the purity control and use magnets as shown in Figure 3-3, then repeat steps 7 and 8.
  10. When a magnet is used, be sure to perform step 2, and tighten deflection yoke mounting screw loosely.




Fig. 3-1.




Fig. 3-2.





Fig. 3-3.

### 3-2. COVERAGE


#### Preparation:

- Before starting, perform FOCUS, H. SIZE, V. SIZE and V. LIN adjustments.
- Set BRIGHTNESS control to fully counterclockwise.
- Feed in the dot pattern.


#### (1) Horizontal and Vertical Static Convergence



4. When the V. STAT magnet is moved in the direction of arrow (a) and (b), Red, Green and Blue dots move as shown below.




1. Adjust H. STAT VR to coincide red, green and blue dots on the center of screen (Horizontal movement)
  2. Adjust V. STAT magnet to coincide red, green and blue dots on the center of screen (Vertical movement)
  3. If the red, green and blue dots do not coincide on the center of screen with H. STAT VR, perform horizontal convergence adjustment using H. STAT VR and V. STAT magnet as shown below. (In this case, H. STAT VR and V. STAT magnet effect each other.)
- Tilt the V. STAT magnet and adjust static convergence to open or close the V. STAT magnet.



If blue dot does not coincide with red and green dots, perform following steps.

Move BMC magnet (a) to correct insufficient H. static convergence.  
Rotate BMC magnet (b) to correct insufficient V. static convergence.

In either case, repeat Beam Landing Adjustment.



## (2) Dynamic Convergence Adjustment

### Preparation:


- Before starting, perform Horizontal and Vertical Static Convergence Adjustment.

1. Loosen deflection yoke screw.
2. Remove deflection yoke spacers.

3. Move the deflection yoke for best convergence as shown below.

4. Tighten the deflection yoke screw.


5. Install the deflection yoke spacers.



### 3-3. WHITE BALANCE ADJUSTMENT

- 1) SCREEN ( $G_2$ ) adjustment
  1. Confirm that  $G_1$  line voltage is  $30 \pm 5$  Vdc.
  2. Adjust CUT OFF(R,B) so that R,B cathode voltage becomes 180 V DC.  
Adjust with  $G_2$  VT immediately prior to the disappearing of the luminscent line.
- 2) W/B adjustment
  1. Input a all white signal.
  2. Set the PICTURE control to minimum and turn the BRIGHT control mechanical center.
  3. Set R CUT OFF(R,B) and RV703 (B CUT OFF) to minimum.
  4. Turn RV701 (SUB BRT) slowly to obtain a faintly visible cross-hatch.  
Note the color tjat first becomes visible by turning RV701.
  5. Adjust the other two BKG controls for best white balance (neutral gray) of the faint cross-hatch.
  6. Set the PICTURE control fully clockwise.  
Observe the screen and adjust the RV1301 (G,H/L), RV1302 (B,H/L) controls for best white balance. (B Board)
  7. Repeat steps 1, through 7.


**B Board**



*RV1301 (G.H/L)  
RV1302 (B.H/L)*

(Component side)

**C Board**



*RV703 (B CUT OFF)  
RV705 (R CUT OFF)  
RV706 (SUB. BRT)  
RV701 (SCRN)*

(Component side)


## SECTION 4 CIRCUIT ADJUSTMENTS

### 4-1. FA BOARDS ADJUSTMENT

#### +B Line Adjustment

1. Supply 220V ac to with variable auto-transformer.
2. Adjust RV651 so that the +B line is  $140V \pm 0.5V$ .
3. Adjust RV652 so that the pin ① or IC651 is  $32 \pm 0.1V$ .

#### FA Board



RV651 (+B ADJ)  
RV652 (REF ADJ)

(Component side)

### 4-2. D BOARD ADJUSTMENTS


#### Horizontal Position Adjustment

1. Check that H center moves to the right and left with horizontal position VR (RV555), then adjust horizontal position to center.


#### Picture Distortion Adjustment

1. Picture distortion adjustment  
Input a signal equivalent to a crosshatch signal.

#### PIN PHASE (RV553)



#### PIN AMP (RV552)



2. Adjust RV554 (H.SIZE) so that H.SIZE is best.
3. Adjust RV555 (H.CENT) so that horizontal position is center.

#### V.SIZE V.CENT

Adjust RV503 and RV509 for a best vertical SIZE Picture.

#### H.FREQ Adjustment

1. Input a color bar signal and short between IC501 pins ① and ①①.  
Also short board IC401 pins ③⑤ and ③⑥.
2. Adjust H.FREQ VR (RV501) so that picture flow is as shown in Figure.
3. After adjustment, remove the connections in step ①.




fo low

fo correct  
(fo=15.734Hz)

fo high

#### D Board





(Component side)

RV501 (H.FREQ)  
IC501 1 11 (H FREQ)  
RV503 (V.SIZE)  
RV555 (H.CENT)  
RV552 (PIN AMP)  
RV509 (V.CENT)  
RV553 (PIN PHASE)  
RV554 (H.SIZE)


### 4-3. HC BOARD ADJUSTMENT

#### H. CENTER Adjustment (DIGITAL RGB)

1. Connect to the digital RGB output connector of a microcomputer.
2. Press to select the RGB mode.
3. Turn the H. CENT VR (RV987--- Rear control panel) to center position.
4. Connect the oscilloscope to pin ④ of HC-2 connector and pin ① of HC-2 connector.
5. Adjust RV986 (H. CENT-2) so that the phase difference level is  $\pm 0.1\mu\text{sec}$ .




#### HC Board



### 4-4. B BOARD ADJUSTMENTS

#### Y Chroma Adjustment


1. Input a PAL color bar signal.
2. Connect an oscilloscope to pin ③⑤ of IC301, and adjust so that chroma component is minimum on pin ③⑤ of IC301 waveform while tracking with L451 (4.43 MHz).



3. Input a NTSC (3.58) color bar signal.
4. Connect an oscilloscope to pin ③⑤ of IC301 and adjust so that chroma component is minimum on pin ③⑤ of IC301 waveform while tracking with L452.

#### COLOR BALANCE Adjustment


1. Input a SECAM color bar signal and set PICTURE to maximum.  
Press "RESET" to set color to standard state.
2. Observe blue output (TP33) waveform on the oscilloscope and adjust L421 (B-Y) so that the black portion of the color bar is the same level as the pedestal.



3. Observe blue output (TP31) waveform on the oscilloscope and adjust L405 (R-Y) so that the black portion of the color bar is the same level as the pedestal.




# 5-1. CIRCUIT BOARDS LOCATION



## 4-4. B BOARD ADJUSTMENTS

### Y Chroma Adjustment


1. Input a PAL color bar signal.
2. Connect an oscilloscope to pin (35) of IC301, and adjust so that chroma component is minimum on pin (35) of IC301 waveform while tracking with L451 (4.43 MHz).




3. Input a NTSC (3.58) color bar signal.
4. Connect an oscilloscope to pin (35) of IC301 and adjust so that chroma component is minimum on pin (35) of IC301 waveform while tracking with L452.

### COLOR BALANCE Adjustment

1. Input a SECAM color bar signal and set PICTURE to maximum.  
Press "RESET" to set color to standard state.
2. Observe blue output (TP33) waveform on the oscilloscope and adjust L421 (B-Y) so that the black portion of the color bar is the same level as the pedestal.



3. Observe blue output (TP31) waveform on the oscilloscope and adjust L405 (R-Y) so that the black portion of the color bar is the same level as the pedestal.



### ANTI-PAL, LINE CRAWLING Adjustment

1. Input a PAL color bar signal and set PICTURE to maximum.  
Press "RESET" to set COLOR, HUE and BRT to standard state.
2. Confirm that there is no color on the first anti-PAL signal frames at the right and left of the picture. If sides while tracking with RV303.
3. Adjust T301 (DAT) for minimum line crawling.
4. Confirm the anti-PAL adjustment in 2, and repeat 3, and 1 if necessary.

### APC Adjustment

#### 4.43 adjustment


1. Input a PAL color bar signal.
2. Short pin (1) and pin (12) on IC301.
3. Adjust CT443 to get color sync.

#### 3.58 adjustment

4. Input a NTSC (3.58 MHz) color bar signal.
5. Adjust CT358 to get color sync.


### ACC, HUE CENT Adjustment

1. Input a PAL color bar signal and set PICTURE maximum.
2. Adjust RV302 (ACC ADJ) so that blue output (TP33) waveform is as shown in figure.



3. Input a NTSC (3.58 or 4.43) color bar signal and set PICTURE to maximum.  
Press "RESET" to set COLOR, HUE and BRIGHTNESS to standard state.
4. Adjust RV318 (S. HUE) so that blue output (TP33) waveform is as shown in figure.

### B Board



CT358 (3.58)  
CT443 (4.43)


L405 (R-Y)  
L421 (B-Y)  
L451 (4.43 MHz)  
L452 (Y/CHROMA)

RV302 (ACC)  
RV303 (φ)  
RV318 (S. HUE)  
T301 (DAT)

## 4-5. SAFETY CHECK ADJUSTMENT

### HOLD DOWN ADJUSTMENT (\*R531)

1. Turn the POWER switch ON, and receive entirely white signals and set the PICTURE and BRIGHTNESS control to maximum.
  2. Confirm that the voltage of the IC1510 (1) pin is more than 15.78V DC when the set is operating normally with 120V AC supply.
  3. Adjust ABL current to 1400 ± 30 μA with PICTURE and BRIGHTNESS. (ammeter 3.0mA dc range)
  4. Confirm that there is less than 18.35V DC where by the raster disappears during operation of hold-down circuit. (HOLD DOWN check point of IC1510 (1) pin)
  5. Adjust ABL current to 210 ± 3 μA with PICTURE and BRIGHTNESS. (ammeter 0.3mA dc range)
  6. Confirm that there is less than 19.25V DC where by the raster disappears during operation of hold-down circuit. (HOLD DOWN check point of IC1510 (1) pin)
- Note: If the hold-down circuit starts operating in the above case, switch OFF the POWER of the set immediately.
7. If above steps is not satisfied, select resistance value of R597 and repeat above steps 1 through 6.







SECTION 5

DIAGRAMS

B Board




5-1. CIRCUIT BOARDS LOCATION




4-5. SAFETY CHECK ADJUSTMENT



HOLD DOWN ADJUSTMENT (\*R531)

- Turn the POWER switch ON, and receive entirely white signals and set the PICTURE and BRIGHTNESS control to maximum.
  - Confirm that the voltage of the IC1510 ① pin is more than 15.78V DC when the set is operating normally with 120V AC supply.
  - Adjust ABL current to  $1400 \pm 30 \mu\text{A}$  with PICTURE and BRIGHTNESS. (ammeter 3.0mA dc range)
  - Confirm that there is less than 18.35V DC where by the raster disappears during operation of hold-down circuit. (HOLD DOWN check point of IC1510 ① pin)
  - Adjust ABL current to  $210 \pm 3 \mu\text{A}$  with PICTURE and BRIGHTNESS. (ammeter 0.3mA dc range)
  - Confirm that there is less than 19.25V DC where by the raster disappears during operation of hold-down circuit. (HOLD DOWN check point of IC1510 ① pin)
- Note: If the hold-down circuit starts operating in the above case, switch OFF the POWER of the set immediately.
7. If above steps is not satisfied, select resistance value of R597 and repeat above steps 1 through 6.




# 5-2. BLOCK DIAGRAM







## 5-3. FRAME SCHEMATIC DIAGRAM



1.

Diagram of the HA (Key Board/Indicator) showing 16 numbered points (64 to 96) and their corresponding labels:

- 64: HUE
- 65: COLOR
- 66: BRT
- 67: NORMAL
- 68: SUP
- 69: BALANCE
- 70: KEY 0
- 71: KEY 1
- 72: +BV
- 73: PAL
- 74: SECAM
- 75: NTSC
- 76: NTSC433

— 31 —

19

20

21

22

A

B

C

D

E



F

G

H


I

J





5-4. SCHEMATIC DIAGRAM AND PRINTED WIRING BOARDS

- Note:**
- All capacitors are in  $\mu\text{F}$  unless otherwise noted.  
50WV or less are not indicated except for electrolytics.  
 $\mu$  :  $\mu\text{F}$
  - All resistors are in ohms,  $\frac{1}{4}\text{W}$  unless otherwise noted.  
 $\text{k}\Omega$  : 1000 $\Omega$ ,  $\text{M}\Omega$  : 1000  $\text{k}\Omega$
  - All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
  - $\square$  : nonflammable resistor.
  - $\triangle$  : internal component.
  - $\square$  : panel designation.
  - $\square$  : adjustment for repair.
  - $\text{---}$  : B+ bus.
  - $\text{---}$  : B- bus.
  - Voltages are dc with respect to ground unless otherwise noted.
  - Readings are taken with a 10  $\text{M}\Omega$  digital multimeter.
  - Voltage variations may be noted due to normal production tolerances.
  - Readings are taken with a color-bar-signal input.
  - no mark : with PAL color-bar signal received.  
( ) : with SECAM color-bar signal received.  
< > : with NTSC (3.58) color-bar signal received.  
[ ] : with NTSC (4.43) color-bar signal received.
  - \* : Selected to yield optimum performance.









QA

ANALOG/DIGITAL DECODER,  
VIDEO/AUDIO BUFFER,  
SYNC PROCESS.

QB

QB

QA

(JACK/CONNECTOR)

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16

## 【QB BOARD】

	PAL	SECAM	NTSC 3.58 4.43
② Q1773 B			
IVp-p(H)	IVp-p(H)	IVp-p(H)	IVp-p(H)
③ Q1789 B			
IVp-p(H)	IVp-p(H)	IVp-p(H)	IVp-p(H)
④ QB-7 ④			
2Vp-p(H)	2Vp-p(H)	2Vp-p(H)	2Vp-p(H)
⑤ Q1776 B			
0.9Vp-p(H)	0.9Vp-p(H)	0.9Vp-p(H)	0.9Vp-p(H)
⑥ Q1830 C			
2Vp-p(H)	2Vp-p(H)	2Vp-p(H)	2Vp-p(H)
⑦ Q1792 B			
0.9Vp-p(H)	0.9Vp-p(H)	0.9Vp-p(H)	0.9Vp-p(H)
⑧ QB-14 ②			
0.9Vp-p(H)	0.9Vp-p(H)	0.9Vp-p(H)	0.9Vp-p(H)

## 【QA BOARD】

① LINEA J7			
IVp-p(H)	IVp-p(H)	IVp-p(H)	IVp-p(H)

## QA Board

IC Q	1811 1810	1809 1808	1823	1831	1807	1832,1784	1817	1812	1822	1781	1796	1795	1806 1805	1804 1776 1775	1814	1799	1813	1815	1825	1792 1793 1790	1775	1779	1826	1827	1778	1777	1776	1819 1818	IC1770	IC1772	1785 1786	1891 1820	IC Q																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																															
D	1703	1776	1775	1774 1711	1709	1707	1777, 1708, 1710	1706	1787	1783	1782	1771	1770	1772 1773	1781	1789	1788	1770	1772	1789	1788	1770	1781	1772	1773	1778	1779	1780	1781	1782	1783	1784	1785	1786	1787	1788	1789	1790	1791	1792	1793	1794	1795	1796	1797	1798	1799	1800	1801	1802	1803	1804	1805	1806	1807	1808	1809	1810	1811	1812	1813	1814	1815	1816	1817	1818	1819	1820	1821	1822	1823	1824	1825	1826	1827	1828	1829	1830	1831	1832	1833	1834	1835	1836	1837	1838	1839	1840	1841	1842	1843	1844	1845	1846	1847	1848	1849	1850	1851	1852	1853	1854	1855	1856	1857	1858	1859	1860	1861	1862	1863	1864	1865	1866	1867	1868	1869	1870	1871	1872	1873	1874	1875	1876	1877	1878	1879	1880	1881	1882	1883	1884	1885	1886	1887	1888	1889	1890	1891	1892	1893	1894	1895	1896	1897	1898	1899	1900	1901	1902	1903	1904	1905	1906	1907	1908	1909	1910	1911	1912	1913	1914	1915	1916	1917	1918	1919	1920	1921	1922	1923	1924	1925	1926	1927	1928	1929	1930	1931	1932	1933	1934	1935	1936	1937	1938	1939	1940	1941	1942	1943	1944	1945	1946	1947	1948	1949	1950	1951	1952	1953	1954	1955	1956	1957	1958	1959	1960	1961	1962	1963	1964	1965	1966	1967	1968	1969	1970	1971	1972	1973	1974	1975	1976	1977	1978	1979	1980	1981	1982	1983	1984	1985	1986	1987	1988	1989	1990	1991	1992	1993	1994	1995	1996	1997	1998	1999	2000	2001	2002	2003	2004	2005	2006	2007	2008	2009	2010	2011	2012	2013	2014	2015	2016	2017	2018	2019	2020	2021	2022	2023	2024	2025	2026	2027	2028	2029	2030	2031	2032	2033	2034	2035	2036	2037	2038	2039	2040	2041	2042	2043	2044	2045	2046	2047	2048	2049	2050	2051	2052	2053	2054	2055	2056	2057	2058	2059	2060	2061	2062	2063	2064	2065	2066	2067	2068	2069	2070	2071	2072	2073	2074	2075	2076	2077	2078	2079	2080	2081	2082	2083	2084	2085	2086	2087	2088	2089	2090	2091	2092	2093	2094	2095	2096	2097	2098	2099	2100	2101	2102	2103	2104	2105	2106	2107	2108	2109	2110	2111	2112	2113	2114	2115	2116	2117	2118	2119	2120	2121	2122	2123	2124	2125	2126	2127	2128	2129	2130	2131	2132	2133	2134	2135	2136	2137	2138	2139	2140	2141	2142	2143	2144	2145	2146	2147	2148	2149	2150	2151	2152	2153	2154	2155	2156	2157	2158	2159	2160	2161	2162	2163	2164	2165	2166	2167	2168	2169	2170	2171	2172	2173	2174	2175	2176	2177	2178	2179	2180	2181	2182	2183	2184	2185	2186	2187	2188	2189	2190	2191	2192	2193	2194	2195	2196	2197	2198	2199	2200	2201	2202	2203	2204	2205	2206	2207	2208	2209	2210	2211	2212	2213	2214	2215	2216	2217	2218	2219	2220	2221	2222	2223	2224	2225	2226	2227	2228	2229	2230	2231	2232	2233	2234	2235	2236	2237	2238	2239	2240	2241	2242	2243	2244	2245	2246	2247	2248	2249	2250	2251	2252	2253	2254	2255	2256	2257	2258	2259	2260	2261	2262	2263	2264	2265	2266	2267	2268	2269	2270	2271	2272	2273	2274	2275	2276	2277	2278	2279	2280	2281	2282	2283	2284	2285	2286	2287	2288	2289	2290	2291	2292	2293	2294	2295	2296	2297	2298	2299	2300	2301	2302	2303	2304	2305	2306	2307	2308	2309	2310	2311	2312	2313	2314	2315	2316	2317	2318	2319	2320	2321	2322	2323	2324	2325	2326	2327	2328	2329	2330	2331	2332	2333	2334	2335	2336	2337	2338	2339	2340	2341	2342	2343	2344	2345	2346	2347	2348	2349	2350	2351	2352	2353	2354	2355	2356	2357	2358	2359	2360	2361	2362	2363	2364	2365	2366	2367	2368	2369	2370	2371	2372	2373	2374	2375	2376	2377	2378	2379	2380	2381	2382	2383	2384	2385	2386	2387	2388	2389	2390	2391	2392	2393	2394	2395	2396	2397	2398	2399	2400	2401	2402	2403	2404	2405	2406	2407	2408	2409	2410	2411	2412	2413	2414	2415	2416	2417	2418	2419	2420	2421	2422	2423	2424	2425	2426	2427	2428	2429	2430	2431	2432	2433	2434	2435	2436	2437	2438	2439	2440	2441	2442	2443	2444	2445	2446	2447	2448	2449	2450	2451	2452	2453	2454	2455	2456	2457	2458	2459	2460	2461	2462	2463	2464	2465	2466	2467	2468	2469	2470	2471	2472	2473	2474	2475	2476	2477	2478	2479	2480	2481	2482	2483	2484	2485	2486	2487	2488	2489	2490	2491	2492	2493	2494	2495	2496	2497	2498	2499	2500	2501	2502	2503	2504	2505	2506	2507	2508	2509	2510	2511	2512	2513	2514	2515	2516	2517	2518	2519	2520	2521	2522	2523	2524	2525	2526	2527	2528	2529	2530	2531	2532	2533	2534	2535	2536	2537	2538	2539	2540	2541	2542	2543	2544	2545	2546	2547	2548	2549	2550	2551	2552	2553	2554	2555	2556	2557	2558	2559	2560	2561	2562	2563	2564	2565	2566	2567	2568	2569	2570	2571	2572	2573	2574	2575	2576	2577	2578	2579	2580	2581	2582	2583	2584	2585	2586	2587	2588	2589	2590	2591	2592	2593	2594	2595	2596	2597	2598	2599	2600	2601	2602	2603	2604	2605	2606	2607	2608	2609	2610	2611	2612	2613	2614	2615	2616	2617	2618	2619	2620	2621	2622	2623	2624	2625	2626	2627	2628	2629	2630	2631	2632	2633	2634	2635	2636	2637	2638	2639	2640	2641	2642	2643	2644	2645	2646	2647	2648	2649	2650	2651	2652	2653	2654	2655	2656	2657	2658	2659	2660	2661	2662	2663	2664	2665	2666	2667	2668	2669	2670	2671	2672	2673	2674	2675	2676	2677	2678	2679	2680	2681	2682	2683	2684	2685	2686	2687	2688	2689	2690	2691	2692	2693	2694	2695	2696	2697	2698	2699	2700	2701	2702	2703	2704	2705	2706	2707	2708	2709	2710	2711	2712	2713	2714	2715	2716	2717	2718	2719	2720	2721	2722	2723	2724	2725	2726	2727	2728	2729	2730	2731	2732	2733	2734	2735	2736	2737	2738	2739	2740	2741	2742	2743	2744	2745	2746	2747	2748	2749	2750	2751	2752	2753	2754	2755	2756	2757	2758	2759	2760	2761	2762	2763	2764	2765	2766	2767	2768	2769	2770	2771	2772	2773	2774	2775	2776	2777	2778	2779	2780	2781	2782	2783	2784	2785	2786	2787	2788	2789	2790	2791	2792	2793	2794	2795	2796	2797	2798	2799	2800	2801	2802	2803	2804	2805	2806	2807	2808	2809	2810	2811	2812	2813	2814	2815	2816	2817	2818	2819	2820	2821	2822	2823	2824	2825	2826	2827	2828	2829	2830	2831	2832	2833	2834	2835	2836	2837	2838	2839	2840	2841	2842	2843	2844	2845	2846	2847	2848	2849	2850	2851	2852	2853	2854	2855	2856	2857	2858	2859	2860	2861	2862	2863	2864	2865	2866	2867	2868	2869	2870	2871	2872	2873	2874	2875	2876	2877	2878	2879	2880	2881	2882	2883	2884	2885	2886	2887	2888	2889	2890	2891	2892	2893	2894	2895	2896	2897	2898	2899	2900	2901	2902	2903	2904	2905	2906	2907	2908	2909	2910	2911	2912	2913	2914	2915	2916	2917	2918	2919	2920	2921	2922	2923	2924	2925	2926	2927	2928	2929	2930	2931	2932	2933	2934	2935	2936	2937	2938	2939	2940	2941	2942	2943	2944	2945	2946	2947	2948	2949	2950	2951	2952	2953	2954	2955	2956	2957	2958	2959	2960	2961	2962	2963	2964	2965	2966	2967	2968	2969	2970	2971	2972	2973	2974	2975	2976	2977	2978	2979	2980	2981	2982	2983	2984	2985	2986	2987	2988	2989	2990	2991	2992	2993	2994	2995	2996	2997	2998	2999	3000





[AUDIO AMP CONTROL.]


K

K

K Board










SECAM/PAL/NTSC DFTFCT, Y/CHROMA PROCESS  
AUTOMATIC WHITE BALANCE, VIDEO D/A CONVERT  
REMOTE CONTROL DECODER, LAST MEMORY,  
LED DRIVE.

B


B

B Board





IC	Q	D	ADJ	TP
1301	109	308		
	IC110	343		
1303	115	309		
1302	112	120		
321, 322	342			
119, 107		362, 126	RV303	
310		124		
		361, 125		
116		121		
393		127		
IC302	301	101		
122, 123	101	123	RV1301	31
105		117, 102	RV1302	17
114		103		14
		112		33
104		110		32
309		344		
		340		
		335		
		345		
117		339		13
		341		16
IC301	108	305, 104	RV302	15
311		334		12
407		118		
		307		11
	353	115		
	IC101			
	358, 355			
	357, 354			
	IC122	457	CT443	18
		354	CT358	
341	406	392	RV318	
		113		19
342	III			
331	IC411	110		
343				
363, 457	118	351	RV301	20
460	403	401		
	IC412			
	405, 315			
362	IC102			
400	IC104			
455	121			
458				
361	IC121			
	316			
	324			
459, 456				
IC401	IC106	450		
	IC107	III		
401				
402				
	IC311			
451				
454				
453				
450				
461				
		442, 444		
		445, 443		
452				
372, 373				
374, 371				
IC	Q	D	ADJ	TP






IC	Q	D	ADJ	TP
1301	109	308		
	IC110	343		
	115	309		
1303	IC103	120		
1302	112	342		
321, 322	119	362	126	
	107	124		
310		361	125	
	116	121		
393		127		
	301			
IC302		101		
122, 123	101	123		
	105	117, 102		
	114	103		
	102	112		
		110		
	104	344		
	103	340		
		335		
309		345		
		339		
	117	341		
IC301	108	305	104	
311		334	118	
407	353	307	115	
	IC101			
358, 355				
357, 354				
	IC122	457	354	
341	406	392	114	
		306		
	113	454	113	
		116		
342	III			
331	IC411	110		
343				
363, 457	118	351		
460	403	401		
	IC412			
	405, 315			
362	IC102			
	400			
	455	IC104		
458	121			
361	IC121			
	316			
	324			
459, 456				
IC401		108		
	IC106	450		
401	IC107			
402	IC311	111		
451				
454				
453				
450		442, 444		
461		445, 443		
452				
372, 373				
374, 371				
IC	Q	D	ADJ	TP

**HA Board****HB Board**


## HC Board








Y BOARD INDICATOR.] **HB** [KEY BOARD INDICATOR.] **HA** **HA** **HB** **HC** **HD** [SWITCH.] **N** [INF AMP.]


19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34





NBoard





HD Board







15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31







[SYNC SEP, H/V OSC, H/S OUT  
PIN CONP, PIN OUT, H/V CONP, BLK.]

D

D









IC, Q	D	ADJ	TP
IC1510 IC1511	1522 1514 558		97
IC1511	1513		85
IC1512	1516		
IC1513	1517		
IC1514	1518		
IC1515	1519		
IC1516	1520		
IC1517	1521		
IC1518	1522		
IC1519	1523		
IC1520	1524		
IC1521	1525		
IC1522	1526		
IC1523	1527		
IC1524	1528		
IC1525	1529		
IC1526	1530		
IC1527	1531		
IC1528	1532		
IC1529	1533		
IC1530	1534		
IC1531	1535		
IC1532	1536		
IC1533	1537		
IC1534	1538		
IC1535	1539		
IC1536	1540		
IC1537	1541		
IC1538	1542		
IC1539	1543		
IC1540	1544		
IC1541	1545		
IC1542	1546		
IC1543	1547		
IC1544	1548		
IC1545	1549		
IC1546	1550		
IC1547	1551		
IC1548	1552		
IC1549	1553		
IC1550	1554		
IC1551	1555		
IC1552	1556		
IC1553	1557		
IC1554	1558		
IC1555	1559		
IC1556	1560		
IC1557	1561		
IC1558	1562		
IC1559	1563		
IC1560	1564		
IC1561	1565		
IC1562	1566		
IC1563	1567		
IC1564	1568		
IC1565	1569		
IC1566	1570		
IC1567	1571		
IC1568	1572		
IC1569	1573		
IC1570	1574		
IC1571	1575		
IC1572	1576		
IC1573	1577		
IC1574	1578		
IC1575	1579		
IC1576	1580		
IC1577	1581		
IC1578	1582		
IC1579	1583		
IC1580	1584		
IC1581	1585		
IC1582	1586		
IC1583	1587		
IC1584	1588		
IC1585	1589		
IC1586	1590		
IC1587	1591		
IC1588	1592		
IC1589	1593		
IC1590	1594		
IC1591	1595		
IC1592	1596		
IC1593	1597		
IC1594	1598		
IC1595	1599		
IC1596	1600		

[C BOARD]




CBoard








**【 C BOARD 】**



## C Board



**FA Board**


**FCBoard**

5-5. SEMICONDUCTORS

BA236  
LA7910




CX-175




CX23025  
HA17558  
NJM4558D  
 $\mu$ PC358C  
 $\mu$ PC4558C




CXA1001AP




CXA1024S




CXK1005P  
SN74LS138N  
TA7630P  
 $\mu$ PD4052BC  
 $\mu$ PD6326C




MC14073BCP




SN74LS09N  
SN74LS86N  
TC4073BP  
 $\mu$ PD1394C  
 $\mu$ PD4066BC  
 $\mu$ PD4073BC




NJM7805H  
NJM7812A  
NJM78M12H  
 $\mu$ PC7805H  
 $\mu$ PC7812H  
 $\mu$ PC78M121-1



TA7273P




TD62381




$\mu$ PC574J




$\mu$ PC1377C




$\mu$ PC1378H



$\mu$ PD750HCU-244



$\mu$ PD8243C



2SA933  
2SA1091  
2SB734  
2SC2551



2SA1048  
2SA1115  
2SC1740  
2SC2458  
2SC2603  
DTA124ES  
DTC124ES  
DTC144ES




2SA1175  
2SC2785




2SB734  
2SC2958  
2SC2959  
2SD773  
2SD774



2SC2334  
2SD1134



2SC2611  
2SC2688



2SD795




2SD1403




2SD1555




2SK523




IN4148  
ISS83  
IS1555  
10E2  
EQA01-06  
ERC24-06S  
ERD28-08  
ES1F  
GP-08D  
RD5,6E-B2  
RD5,6EBZ7S  
RD6,2E-B1  
RD6,2E-B2  
RD6,2E-L2  
RD12E-B2  
RD13E-L2  
RD27E-B2  
RGP01-17  
RGP01-17PKG23  
RGP10G-PKG23




ISS119  
ISS133  
ISS148  
HZS3.6NB1  
HZS5.1NB  
HZS5.1NB2  
HZS6.8NB2  
HZS10NB2  
HZS13NB3  
MTZJ5.1B  
MTZJ13C  
RD3.6ES-B1  
RD5.1ES-B  
RD5.1ES-B2  
RD5.1ES-B3  
RD5.6ES-B3  
RD6.2ES-B1  
RD6.2ES-B2  
RD6.8ES-B  
RD7.5ES-B2  
RD8.2ES-B1  
RD8.2ES-B2  
RD9.1ES-B3  
RD10ES-B2  
RD13ES-B3




CTU-12S




EQB9.1ES-06  
ERC25-06  
RH-1A




ERC26-15S  
GH3F  
U05G  
V30N




ERD29-08



MC931




S3WB60Z



V19E  
V19G



TLP581






SECTION 6

EXPLODED VIEWS


NOTE:

- Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.


2SC2611  
2SC2688




2SD795




2SD1403




2SD1555




2SK523




IN4148  
ISS83  
IS1555  
10E2  
EQA01-06  
ERC24-06S  
ERD28-08  
ES1F  
GP-08D  
RD5,6E-B2  
RD5,6EBZ7S  
RD6,2E-B1  
RD6,2E-B2  
RD6,2E-L2  
RD12E-B2  
RD13E-L2  
RD27E-B2  
RGP01-17  
RGP01-17PKG23  
RGP10G-PKG23




ISS119  
ISS133  
ISS148  
HZS3.6NB1  
HZS5.1NB  
HZS5.1NB2  
HZS6.8NB2  
HZS10NB2  
HZS13NB3  
MTZJ5.1B  
MTZJ13C  
RD3.6ES-B1  
RD5.1ES-B  
RD5.1ES-B2  
RD5.1ES-B3  
RD5.6ES-B3  
RD6.2ES-B1  
RD6.2ES-B2  
RD6.8ES-B  
RD7.5ES-B2  
RD8.2ES-B1  
RD8.2ES-B2  
RD9.1ES-B3  
RD10ES-B2  
RD13ES-B3




CTU-12S




EQB9.1ES-06  
ERC25-06  
RH-1A




ERC26-15S  
GH3F  
U05G  
V30N




ERD29-08




MC931




S3WB60Z



V19E  
V19G




TLP581



6-1. PICTURE TUBE

• BVTP 3x12 7-685-648-79



No.	Part No.	Description	Remark	No.	Part No.	Description
1	*A-1389-865-A	K BOARD, COMPLETE		8	4-371-176-01	
2	*A-1-237-614-11	RESISTOR ASSY, HIGH-VOLTAGE		9	4-371-181-01	
3	4-319-520-11	SCREW, SPECIAL (+PW4X30)		10	X-4374-166-3	
4	*1-621-541-11	HD BOARD		11	4-316-003-21	
5	4-381-166-01	KNOB (A), CONTROL		12	*A-1270-213-A	
6	*A-1375-066-A	HC BOARD, COMPLETE		13	*3-680-721-00	
7	4-382-035-21	PANEL, CONTROL		14	*A-1270-212-A	
					*A-1270-223-A	

SECTION 6  
EXPLODED VIEWS

## NOTE:


- Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.

- Items marked "★" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.


The components identified by shading and mark ▲ are critical for safety. Replace only with part number specified.

## 6-1. PICTURE TUBE

● BVTP 3x12 7-685-648-79



## 6-2. CHASSIS




The components identified by shading and mark ▲ are critical for safety. Replace only with part number specified.

No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
1	*A-1389-865-A	K BOARD, COMPLETE		8	4-371-176-01	CAP, SQUARE	
2	▲1-237-614-11	RESISTOR ASSY, HIGH-VOLTAGE		9	4-371-181-01	CAP	
3	4-319-520-11	SCREW, SPECIAL (+PW4X30)		10	X-4374-166-3	COVER ASSY, REAR	11
4	*1-621-541-11	HD BOARD		11	4-316-003-21	HOLDER, CORD	
5	4-381-166-01	KNOB (A), CONTROL		12	*A-1270-213-A	QB BOARD, COMPLETE	
6	*A-1375-066-A	HC BOARD, COMPLETE		13	*3-680-721-00	HOLDER, CHASSIS	
7	4-382-035-21	PANEL, CONTROL		14	*A-1270-212-A	QA BOARD, COMPLETE (AEP, AUS ONLY)	
					*A-1270-223-A	QA BOARD, COMPLETE (WG ONLY)	

No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
51	1-464-803-11	KEY BOARD UNIT (A)		64	*4-379-167-01	COVER (MAIN), CV	
52	1-464-804-11	KEY BOARD UNIT (B)		65	*A-1330-801-A	C BOARD, COMPLETE	
53	X-4374-194-1	BEZEL ASSY	54	66	*4-379-160-01	COVER (REAR LID), CV	
54	3-703-083-00	+ BV 3X25		67	4-369-318-00	SPRING, TENSION	
55	X-4374-195-1	CABINET ASSY	56, 57	68	*4-369-319-00	BAND, COIL	
56	3-703-025-12	BOLT M5, HEXAGON-HEAD		69	▲1-426-315-11	COIL, DEMAGNETIZATION	
57	4-319-520-11	SCREW, SPECIAL (+PW4X30)		70	*4-383-128-01	COVER, MAIN SWITCH	
58	▲8-736-955-05	PICTURE TUBE (A51JKQ10X)		71	*4-371-182-01	SHAFT	
59	4-373-615-02	WASHER, CRT POSITIONING		72	▲1-554-965-12	SWITCH, PUSH (AC POWER) (1 KEY)	
60	4-306-034-00	FLANGE NUT, (B) 5MM		73	4-308-870-00	CLIP, LEAD WIRE	
61	3-703-003-00	SPACER, DY		74	1-452-032-00	MAGNET, DISK; 10MM Ø	
62	▲1-451-295-11	DEFLECTION YOKE (SY-153E)		75	1-452-094-00	MAGNET, ROTATABLE DISK; 15MM Ø	
63	1-452-277-00	MAGNET, BMC		76	X-4308-815-0	PERMALLOY ASSY, CONVERGENCE	

### 6-3. BACK COVER


- BVTP 3x12 7-685-648-79
- ▲ BVTP 4x12 7-685-661-14



The components identified by shading and mark ▲ are critical for safety. Replace only with part number specified.

No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
101	*A-1345-708-A	D BOARD, COMPLETE		105	▲*4-364-726-01	BUSHING, AC CORD	
102	▲1-439-372-32	TRANSFORMER ASSY, FLYBACK		106	▲1-534-820-13	POWER CORD (AEP, AUS ONLY)	
103	*A-1245-395-A	FA BOARD, COMPLETE (AEP, AUS ONLY)	104	▲1-559-409-11	POWER CORD (WG ONLY)		
104	*A-1245-414-A	FA BOARD, COMPLETE (WG ONLY)	104	107	*A-1135-448-A	B BOARD, COMPLETE	
104	*1-621-548-11	FC BOARD					

**6-4. KEY BOARD UNIT**



No.	Part No.	Description
1	9-990-892-01	ILLUMINATOR A
2	9-990-891-01	REFLECTOR A
3	*9-992-308-01	HA BOARD
4	9-990-895-01	SPACER
5	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)
6	9-990-894-01	TAPPING SCREW
7	9-992-310-01	FRAME ASSY
8	9-992-309-01	HARNESS

Remark

1,2

No.	Part No.	Description
1	9-990-892-01	ILLUMINATOR A
2	9-990-891-01	REFLECTOR A
4	9-990-895-01	SPACER
5	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)
6	9-990-894-01	TAPPING SCREW
7	9-990-899-01	KEY TOP
8	9-990-902-01	COIL SPRING
9	9-990-900-01	STOPPER
10	8-741-138-70	DETECTOR (BX1387)
11	*9-990-898-01	N BOARD
12	*9-992-401-01	HB BOARD
13	9-992-402-01	FRAME ASSY

Remark

1,2,7,8,9

SECTION 7  
ELECTRICAL PARTS LIST

B

## NOTE:

The components identified by shading and mark  $\Delta$  are critical for safety. Replace only with part number specified.

- Items marked "★" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

## CAPACITORS

- MF :  $\mu$ F, PF :  $\mu$ PF

## RESISTORS

- All resistors are in ohms
- F : nonflammable

## COILS

- MMH : mH, UH :  $\mu$ H

When indicating parts by reference number, please include the board name.

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
	*A-1135-448-A	B BOARD, COMPLETE *****		C138	1-123-307-00	ELECT 100MF	20% 10V
		CONNECTOR		C139	1-123-356-00	ELECT 10MF	20% 16V
B1	*1-566-054-11	PIN, CONNECTOR 2P		C140	1-123-356-00	ELECT 10MF	20% 16V
B2	*1-566-057-11	PIN, CONNECTOR 5P		C141	1-123-330-00	ELECT 22MF	20% 16V
B4	*1-566-055-11	PIN, CONNECTOR 3P		C161	1-123-333-00	ELECT 100MF	20% 25V
B5	*1-566-059-11	PIN, CONNECTOR 7P					
B6	*1-566-056-11	PIN, CONNECTOR 4P		C162	1-123-321-00	ELECT 220MF	20% 16V
				C167	1-101-004-00	CERAMIC 0.01MF	50V
B7	*1-566-058-11	PIN, CONNECTOR 6P		C168	1-123-356-00	ELECT 10MF	20% 16V
B8	*1-566-059-11	PIN, CONNECTOR 7P		C169	1-123-356-00	ELECT 10MF	20% 25V
B9	*1-566-061-11	PIN, CONNECTOR 9P		C170	1-101-004-00	CERAMIC 0.01MF	50V
B10	*1-566-065-11	PIN, CONNECTOR 13P					
B11	*1-566-061-11	PIN, CONNECTOR 9P		C171	1-123-356-00	ELECT 10MF	20% 16V
				C173	1-101-004-00	CERAMIC 0.01MF	50V
B13	*1-566-054-11	PIN, CONNECTOR 2P		C174	1-101-004-00	CERAMIC 0.01MF	50V
B14	*1-566-057-11	PIN, CONNECTOR 5P		C175	1-101-006-00	CERAMIC 0.047MF	50V
B15	*1-508-766-00	4P PLUG (M)		C177	1-119-354-00	ELECT 330MF	10V
B16	*1-566-056-11	PIN, CONNECTOR 4P					
B17	*1-566-054-11	PIN, CONNECTOR 2P		C178	1-101-004-00	CERAMIC 0.01MF	50V
				C179	1-101-006-00	CERAMIC 0.047MF	50V
B18	*1-566-055-11	PIN, CONNECTOR 3P		C180	1-123-307-00	ELECT 100MF	20% 10V
B19	*1-566-057-11	PIN, CONNECTOR 5P		C181	1-123-332-00	ELECT 47MF	20% 16V
B20	*1-566-058-11	PIN, CONNECTOR 6P		C182	1-101-006-00	CERAMIC 0.047MF	50V
B21	*1-566-054-11	PIN, CONNECTOR 2P					
		CAPACITOR		C183	1-119-352-00	ELECT 100MF	10V
C101	1-123-356-00	ELECT 10MF	20% 16V	C185	1-123-307-00	ELECT 100MF	20% 10V
C103	1-102-973-00	CERAMIC 100PF	5% 50V	C186	1-123-356-00	ELECT 10MF	20% 16V
C104	1-123-306-00	ELECT 47MF	20% 10V	C187	1-123-330-00	ELECT 22MF	20% 16V
C105	1-136-161-00	FILM 0.047MF	5% 50V	C301	1-123-333-00	ELECT 100MF	20% 16V
C106	1-102-963-00	CERAMIC 33PF	5% 50V				
				C302	1-101-888-00	CERAMIC 68PF	5% 50V
C107	1-102-963-00	CERAMIC 33PF	5% 50V	C303	1-123-369-00	ELECT 4.7MF	20% 25V
C108	1-102-978-00	CERAMIC 220PF	5% 50V	C304	1-123-356-00	ELECT 10MF	20% 16V
C110	1-123-333-00	ELECT 100MF	20% 25V	C305	1-110-201-00	MYLAR 0.0033MF	5% 50V
C112	1-123-335-00	ELECT 330MF	20% 25V	C306	1-101-006-00	CERAMIC 0.047MF	50V
C113	1-123-318-00	ELECT 33MF	20% 16V				
				C307	1-101-006-00	CERAMIC 0.047MF	50V
C114	1-123-333-00	ELECT 100MF	20% 25V	C308	1-123-381-00	ELECT 2.2MF	20% 50V
C115	1-123-333-00	ELECT 100MF	20% 16V	C309	1-102-946-00	CERAMIC 9PF	0.5PF 50V
C116	1-101-006-00	CERAMIC 0.047MF	50V	C310	1-123-356-00	ELECT 10MF	20% 16V
C118	1-101-004-00	CERAMIC 0.01MF	50V	C311	1-136-157-00	FILM 0.022MF	5% 50V
C119	1-123-330-00	ELECT 22MF	20% 16V				
				C312	1-136-157-00	FILM 0.022MF	5% 50V
C120	1-123-330-00	ELECT 22MF	20% 25V	C313	1-102-074-00	CERAMIC 0.001MF	10% 50V
C121	1-123-356-00	ELECT 10MF	20% 16V	C314	1-101-006-00	CERAMIC 0.047MF	50V
C123	1-101-006-00	CERAMIC 0.047MF	50V	C315	1-101-006-00	CERAMIC 0.047MF	50V
C125	1-123-380-00	ELECT 1MF	20% 50V	C316	1-136-169-00	FILM 0.22MF	5% 50V
C126	1-123-380-00	ELECT 1MF	20% 50V				
				C317	1-102-074-00	CERAMIC 0.001MF	10% 50V
C127	1-123-380-00	ELECT 1MF	20% 50V	C322	1-101-006-00	CERAMIC 0.047MF	50V
C128	1-123-380-00	ELECT 1MF	20% 50V	C323	1-124-464-11	ELECT 0.22MF	20% 50V
C131	1-130-475-00	MYLAR 0.0022MF	5% 50V	C324	1-124-464-11	ELECT 0.22MF	20% 50V
C133	1-123-380-00	ELECT 1MF	20% 50V	C325	1-123-333-00	ELECT 100MF	20% 16V
C134	1-123-380-00	ELECT 1MF	20% 50V				
				C326	1-124-464-11	ELECT 0.22MF	20% 50V
C135	1-123-381-00	ELECT 2.2MF	20% 50V	C327	1-102-111-00	CERAMIC 270PF	10% 50V
C136	1-101-006-00	CERAMIC 0.047MF	50V	C330	1-101-006-00	CERAMIC 0.047MF	50V
C137	1-123-307-00	ELECT 100MF	20% 10V	C331	1-123-380-00	ELECT 1MF	20% 50V
				C332	1-136-161-00	FILM 0.047MF	5% 50V
				C333	1-102-959-00	CERAMIC 22PF	5% 50V
				C334	1-123-380-00	ELECT 1MF	20% 50V
				C335	1-123-307-00	ELECT 100MF	20% 10V



B

Ref.No.	Part No.	Description
D110	8-719-911-19	DIODE 1SS119
D111	8-719-110-08	DIODE RD8.2ES-B2
D112	8-719-911-19	DIODE 1SS119
D113	8-719-911-19	DIODE 1SS119
D114	8-719-911-19	DIODE 1SS119
D115	8-719-109-83	DIODE RD5.1ES-B
D116	8-719-109-90	DIODE RD5.6ES-B3
D117	8-719-911-19	DIODE 1SS119
D118	8-719-911-19	DIODE 1SS119
D120	8-719-911-19	DIODE 1SS119
D121	8-719-911-19	DIODE 1SS119
D123	8-719-911-19	DIODE 1SS119
D124	8-719-911-19	DIODE 1SS119
D125	8-719-911-19	DIODE 1SS119
D126	8-719-109-95	DIODE RD6.8ES-B
D127	8-719-109-95	DIODE RD6.8ES-B
D305	8-719-911-19	DIODE 1SS119
D306	8-719-911-19	DIODE 1SS119
D307	8-719-911-19	DIODE 1SS119
D308	8-719-911-19	DIODE 1SS119
D309	8-719-911-19	DIODE 1SS119
D334	8-719-110-15	DIODE RD10ES-B
D335	8-719-911-19	DIODE 1SS119
D339	8-719-911-19	DIODE 1SS119
D340	8-719-911-19	DIODE 1SS119
D341	8-719-911-19	DIODE 1SS119
D342	8-719-110-15	DIODE RD10ES-B
D343	8-719-110-15	DIODE RD10ES-B
D344	8-719-110-15	DIODE RD10ES-B
D345	8-719-911-19	DIODE 1SS119
D351	8-719-911-19	DIODE 1SS119
D354	8-719-911-19	DIODE 1SS119
D361	8-719-911-19	DIODE 1SS119
D362	8-719-911-19	DIODE 1SS119
D392	8-719-911-19	DIODE 1SS119
D401	8-719-911-19	DIODE 1SS119
D442	8-719-911-19	DIODE 1SS119
D443	8-719-911-19	DIODE 1SS119
D444	8-719-911-19	DIODE 1SS119
D445	8-719-911-19	DIODE 1SS119
D450	8-719-911-19	DIODE 1SS119
D454	8-719-911-19	DIODE 1SS119
D457	8-719-911-19	DIODE 1SS119

DELAY LINE

DL301	1-415-122-31	DELAY LINE, 1H (PAL)
DL401	1-415-380-11	DELAY LINE, Y

IC

IC101	8-759-113-02	IC UPD7508HCU-244
IC102	8-752-321-18	IC CXK1005P
IC103	8-759-102-28	IC UPD6326C
IC104	8-759-182-43	IC UPD8243C

Ref.No.	Part No.	Description	Remark
IC106	8-759-207-07	IC TD62381P	
IC107	8-759-207-07	IC TD62381P	
IC110	8-759-140-66	IC UPD4066BC	
IC121	8-759-171-05	IC UPC7805H	
	*4-363-146-00	HEAT SINK, V.OUT; IC121	
IC122	8-759-700-06	IC NJM7812B	
	*4-323-833-00	HEAT SINK, PIN OUT; IC122	
IC301	8-752-030-86	IC CXA1001AP	
IC302	8-752-030-31	IC CXA1024S	
IC311	8-759-240-73	IC TC4073BP	
IC401	8-751-750-00	IC CX175	
IC411	8-759-135-80	IC UPC358C	
IC412	8-759-140-66	IC UPD4066BC	
<u>COIL</u>			
L101	1-408-424-00	MICRO INDUCTOR 180UH	
L104	1-408-424-00	MICRO INDUCTOR 180UH	
L105	1-408-424-00	MICRO INDUCTOR 180UH	
L161	1-407-364-00	COIL, SPOOK CHOKE 3.3UH	
L333	1-408-416-00	MICRO INDUCTOR 39UH	
L337	1-408-160-00	MICRO INDUCTOR 15MMH	
L405	1-404-496-00	COIL	
L406	1-408-411-00	MICRO INDUCTOR 15UH	
L420	1-408-411-00	MICRO INDUCTOR 15UH	
L421	1-404-496-00	COIL	
L430	1-408-245-00	MICRO INDUCTOR 22MMH	
L431	1-408-414-00	MICRO INDUCTOR 27UH	
L432	1-408-415-00	MICRO INDUCTOR 33UH	
L435	1-408-408-00	MICRO INDUCTOR 8.2UH	
L451	1-404-495-00	COIL	
L452	1-404-495-00	COIL	
L455	1-408-163-00	MICRO INDUCTOR 5.6MMH	
<u>IC LINK</u>			
PS1	1-532-605-00	LINK, IC	
PS2	1-532-637-00	LINK, IC	
<u>TRANSISTOR</u>			
Q101	8-729-117-54	TRANSISTOR 2SA1175	
Q102	8-729-117-54	TRANSISTOR 2SA1175	
Q103	8-729-178-54	TRANSISTOR 2SC2785	
Q104	8-729-178-54	TRANSISTOR 2SC2785	
Q105	8-729-178-54	TRANSISTOR 2SC2785	
Q107	8-729-900-36	TRANSISTOR DTC124ES	
Q108	8-729-178-54	TRANSISTOR 2SC2785	
Q109	8-729-117-54	TRANSISTOR 2SA1175	
Q110	8-729-117-54	TRANSISTOR 2SA1175	
Q111	8-729-103-43	TRANSISTOR 2SB734	
Q112	8-729-178-54	TRANSISTOR 2SC2785	
Q113	8-729-178-54	TRANSISTOR 2SC2785	
Q114	8-729-178-54	TRANSISTOR 2SC2785	
Q115	8-729-900-36	TRANSISTOR DTC124ES	
Q116	8-729-117-54	TRANSISTOR 2SA1175	

**B**

Ref.No.	Part No.	Description
Q117	8-729-178-54	TRANSISTOR 2SC2785
Q118	8-729-117-54	TRANSISTOR 2SA1175
Q119	8-729-117-54	TRANSISTOR 2SA1175
Q121	8-729-133-42	TRANSISTOR 2SC2334-L
	*4-363-146-00	HEAT SINK, V.OUT; Q121
Q122	8-729-117-54	TRANSISTOR 2SA1175
Q123	8-729-178-54	TRANSISTOR 2SC2785
Q301	8-729-117-54	TRANSISTOR 2SA1175
Q309	8-729-178-54	TRANSISTOR 2SC2785
Q310	8-729-117-54	TRANSISTOR 2SA1175
Q311	8-729-177-43	TRANSISTOR 2SD774
Q315	8-729-178-54	TRANSISTOR 2SC2785
Q316	8-729-178-54	TRANSISTOR 2SC2785
Q321	8-729-178-54	TRANSISTOR 2SC2785
Q322	8-729-178-54	TRANSISTOR 2SC2785
Q324	8-729-178-54	TRANSISTOR 2SC2785
Q331	8-729-178-54	TRANSISTOR 2SC2785
Q341	8-729-178-54	TRANSISTOR 2SC2785
Q342	8-729-178-54	TRANSISTOR 2SC2785
Q343	8-729-178-54	TRANSISTOR 2SC2785
Q353	8-729-178-54	TRANSISTOR 2SC2785
Q354	8-729-900-36	TRANSISTOR DTC124ES
Q355	8-729-178-54	TRANSISTOR 2SC2785
Q357	8-729-117-54	TRANSISTOR 2SA1175
Q358	8-729-900-36	TRANSISTOR DTC124ES
Q361	8-729-117-54	TRANSISTOR 2SA1175
Q362	8-729-117-54	TRANSISTOR 2SA1175
Q363	8-729-117-54	TRANSISTOR 2SA1175
Q371	8-729-178-54	TRANSISTOR 2SC2785
Q372	8-729-178-54	TRANSISTOR 2SC2785
Q373	8-729-178-54	TRANSISTOR 2SC2785
Q374	8-729-178-54	TRANSISTOR 2SC2785
Q393	8-729-117-54	TRANSISTOR 2SA1175
Q400	8-729-178-54	TRANSISTOR 2SC2785
Q401	8-729-178-54	TRANSISTOR 2SC2785
Q402	8-729-178-54	TRANSISTOR 2SC2785
Q403	8-729-117-54	TRANSISTOR 2SA1175
Q405	8-729-178-54	TRANSISTOR 2SC2785
Q406	8-729-117-54	TRANSISTOR 2SA1175
Q407	8-729-178-54	TRANSISTOR 2SC2785
Q450	8-729-117-54	TRANSISTOR 2SA1175
Q451	8-729-178-54	TRANSISTOR 2SC2785
Q452	8-729-178-54	TRANSISTOR 2SC2785
Q453	8-729-117-54	TRANSISTOR 2SA1175
Q454	8-729-117-54	TRANSISTOR 2SA1175
Q455	8-729-178-54	TRANSISTOR 2SC2785
Q456	8-729-117-54	TRANSISTOR 2SA1175
Q457	8-729-178-54	TRANSISTOR 2SC2785
Q458	8-729-117-54	TRANSISTOR 2SA1175
Q459	8-729-117-54	TRANSISTOR 2SA1175
Q460	8-729-178-54	TRANSISTOR 2SC2785
Q461	8-729-178-54	TRANSISTOR 2SC2785
Q1301	8-729-178-54	TRANSISTOR 2SC2785

Remark	Ref.No.	Part No.	Description	Remark
	Q1302	8-729-178-54	TRANSISTOR 2SC2785	
	Q1303	8-729-117-54	TRANSISTOR 2SA1175	
			<u>RESISTOR</u>	
	R101	1-249-395-11	CARBON 15 5% 1/6W	
	R102	1-249-395-11	CARBON 15 5% 1/6W	
	R103	1-249-441-11	CARBON 100K 5% 1/6W	
	R104	1-249-441-11	CARBON 100K 5% 1/6W	
	R105	1-247-805-00	CARBON 82 5% 1/6W	
	R106	1-249-413-11	CARBON 470 5% 1/6W	
	R107	1-249-411-11	CARBON 330 5% 1/6W	
	R108	1-249-441-11	CARBON 100K 5% 1/6W	
	R109	1-249-433-11	CARBON 22K 5% 1/6W	
	R110	1-249-465-11	CARBON 47K 5% 1/4W	
	R111	1-249-437-11	CARBON 47K 5% 1/6W	
	R114	1-249-437-11	CARBON 47K 5% 1/6W	
	R116	1-249-414-11	CARBON 560 5% 1/6W	
	R117	1-249-429-11	CARBON 10K 5% 1/6W	
	R118	1-249-429-11	CARBON 10K 5% 1/6W	
	R119	1-249-429-11	CARBON 10K 5% 1/6W	
	R121	1-215-867-00	METAL OXIDE 470 5% 1W	F
	R122	1-249-417-11	CARBON 1K 5% 1/6W	
	R123	1-216-357-00	METAL OXIDE 4.7 5% 1W	F
	R124	1-249-433-11	CARBON 22K 5% 1/6W	
	R125	1-249-435-11	CARBON 33K 5% 1/6W	
	R126	1-249-431-11	CARBON 15K 5% 1/6W	
	R127	1-249-417-11	CARBON 1K 5% 1/6W	
	R128	1-249-434-11	CARBON 27K 5% 1/6W	
	R129	1-247-717-11	CARBON 2.2K 5% 1/4W	
	R130	1-247-706-11	CARBON 330 5% 1/4W	
	R131	1-249-409-11	CARBON 220 5% 1/6W	
	R132	1-249-409-11	CARBON 220 5% 1/6W	
	R133	1-249-421-11	CARBON 2.2K 5% 1/6W	
	R134	1-249-421-11	CARBON 2.2K 5% 1/6W	
	R135	1-249-437-11	CARBON 47K 5% 1/6W	
	R136	1-249-417-11	CARBON 1K 5% 1/6W	
	R137	1-249-421-11	CARBON 2.2K 5% 1/6W	
	R138	1-249-421-11	CARBON 2.2K 5% 1/6W	
	R139	1-249-421-11	CARBON 2.2K 5% 1/6W	
	R140	1-249-421-11	CARBON 2.2K 5% 1/6W	
	R141	1-247-717-11	CARBON 2.2K 5% 1/4W	
	R142	1-249-421-11	CARBON 2.2K 5% 1/6W	
	R143	1-249-429-11	CARBON 10K 5% 1/6W	
	R144	1-249-429-11	CARBON 10K 5% 1/6W	
	R145	1-249-437-11	CARBON 47K 5% 1/6W	
	R146	1-249-425-11	CARBON 4.7K 5% 1/6W	
	R147	1-249-441-11	CARBON 100K 5% 1/6W	
	R148	1-249-434-11	CARBON 27K 5% 1/6W	
	R149	1-249-427-11	CARBON 6.8K 5% 1/6W	
	R150	1-249-427-11	CARBON 6.8K 5% 1/6W	
	R151	1-249-423-11	CARBON 3.3K 5% 1/6W	
	R152	1-249-421-11	CARBON 2.2K 5% 1/6W	
	R153	1-249-421-11	CARBON 2.2K 5% 1/6W	



B

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R154	1-249-421-11	CARBON	2.2K 5% 1/6W	R313	1-249-421-11	CARBON	2.2K 5% 1/6W
R155	1-247-717-11	CARBON	2.2K 5% 1/4W	R314	1-249-409-11	CARBON	220 5% 1/6W
R156	1-249-423-11	CARBON	3.3K 5% 1/6W	R315	1-249-433-11	CARBON	22K 5% 1/6W
R157	1-249-433-11	CARBON	22K 5% 1/6W	R316	1-249-435-11	CARBON	33K 5% 1/6W
R158	1-249-417-11	CARBON	1K 5% 1/6W	R317	1-249-421-11	CARBON	2.2K 5% 1/6W
R159	1-249-418-11	CARBON	1.2K 5% 1/6W	R318	1-249-409-11	CARBON	220 5% 1/6W
R160	1-249-397-11	CARBON	22 5% 1/6W	R319	1-249-433-11	CARBON	22K 5% 1/6W
R161	1-249-397-11	CARBON	22 5% 1/6W	R320	1-249-435-11	CARBON	33K 5% 1/6W
R162	1-249-397-11	CARBON	22 5% 1/6W	R321	1-249-435-11	CARBON	33K 5% 1/6W
R163	1-249-397-11	CARBON	22 5% 1/6W	R322	1-249-429-11	CARBON	10K 5% 1/6W
R164	1-249-397-11	CARBON	22 5% 1/6W	R323	1-249-441-11	CARBON	100K 5% 1/6W
R165	1-247-692-11	CARBON	22 5% 1/4W	R324	1-249-441-11	CARBON	100K 5% 1/6W
R166	1-249-397-11	CARBON	22 5% 1/6W	R326	1-249-441-11	CARBON	100K 5% 1/6W
R167	1-249-397-11	CARBON	22 5% 1/6W	R327	1-249-423-11	CARBON	3.3K 5% 1/6W
R168	1-249-397-11	CARBON	22 5% 1/6W	R328	1-249-423-11	CARBON	3.3K 5% 1/6W
R169	1-249-397-11	CARBON	22 5% 1/6W	R329	1-249-423-11	CARBON	3.3K 5% 1/6W
R170	1-249-397-11	CARBON	22 5% 1/6W	R330	1-249-417-11	CARBON	1K 5% 1/6W
R171	1-249-397-11	CARBON	22 5% 1/6W	R331	1-215-493-00	CARBON	1M 5% 1/6W
R172	1-249-397-11	CARBON	22 5% 1/6W	R332	1-215-479-00	CARBON	270K 5% 1/6W
R173	1-249-397-11	CARBON	22 5% 1/6W	R333	1-249-414-11	CARBON	560 5% 1/6W
R174	1-249-429-11	CARBON	10K 5% 1/6W	R334	1-247-883-00	CARBON	150K 5% 1/6W
R175	1-249-429-11	CARBON	10K 5% 1/6W	R335	1-249-413-11	CARBON	470 5% 1/6W
R176	1-247-725-11	CARBON	10K 5% 1/4W	R336	1-249-409-11	CARBON	220 5% 1/6W
R177	1-249-433-11	CARBON	22K 5% 1/6W	R337	1-249-427-11	CARBON	6.8K 5% 1/6W
R178	1-249-433-11	CARBON	22K 5% 1/6W	R338	1-249-421-11	CARBON	2.2K 5% 1/6W
R179	1-249-425-11	CARBON	4.7K 5% 1/6W	R339	1-249-417-11	CARBON	1K 5% 1/6W
R181	1-249-435-11	CARBON	33K 5% 1/6W	R340	1-249-421-11	CARBON	2.2K 5% 1/6W
R182	1-247-849-00	CARBON	5.6K 5% 1/6W	R341	1-249-422-11	CARBON	2.7K 5% 1/6W
R183	1-249-433-11	CARBON	22K 5% 1/6W	R342	1-249-428-11	CARBON	8.2K 5% 1/6W
R184	1-249-435-11	CARBON	33K 5% 1/6W	R343	1-249-433-11	CARBON	22K 5% 1/6W
R185	1-247-713-11	CARBON	1K 5% 1/4W	R345	1-249-439-11	CARBON	68K 5% 1/6W
R186	1-249-417-11	CARBON	1K 5% 1/6W	R346	1-247-849-00	CARBON	5.6K 5% 1/6W
R187	1-249-417-11	CARBON	1K 5% 1/6W	R350	1-249-413-11	CARBON	470 5% 1/6W
R188	1-249-417-11	CARBON	1K 5% 1/6W	R351	1-249-405-11	CARBON	100 5% 1/6W
R189	1-249-417-11	CARBON	1K 5% 1/6W	R352	1-249-433-11	CARBON	22K 5% 1/6W
R190	1-249-417-11	CARBON	1K 5% 1/6W	R353	1-249-420-11	CARBON	1.8K 5% 1/6W
R191	1-249-414-11	CARBON	560 5% 1/6W	R354	1-249-435-11	CARBON	33K 5% 1/6W
R192	1-249-417-11	CARBON	1K 5% 1/6W	R355	1-249-433-11	CARBON	22K 5% 1/6W
R193	1-249-423-11	CARBON	3.3K 5% 1/6W	R356	1-249-437-11	CARBON	47K 5% 1/6W
R194	1-249-423-11	CARBON	3.3K 5% 1/6W	R357	1-249-430-11	CARBON	12K 5% 1/6W
R195	1-249-421-11	CARBON	2.2K 5% 1/6W	R358	1-249-435-11	CARBON	33K 5% 1/6W
R196	1-249-414-11	CARBON	560 5% 1/6W	R359	1-247-883-00	CARBON	150K 5% 1/6W
R197	1-249-421-11	CARBON	2.2K 5% 1/6W	R360	1-247-708-11	CARBON	470 5% 1/4W
R198	1-249-405-11	CARBON	100 5% 1/6W	R361	1-249-417-11	CARBON	1K 5% 1/6W
R199	1-249-417-11	CARBON	1K 5% 1/6W	R362	1-249-429-11	CARBON	10K 5% 1/6W
R303	1-249-469-11	CARBON	100K 5% 1/4W	R363	1-249-417-11	CARBON	1K 5% 1/6W
R304	1-249-436-11	CARBON	39K 5% 1/6W	R364	1-249-412-11	CARBON	390 5% 1/6W
R305	1-247-883-00	CARBON	150K 5% 1/6W	R365	1-247-723-11	CARBON	6.8K 5% 1/4W
R306	1-249-435-11	CARBON	33K 5% 1/6W	R366	1-247-891-00	CARBON	330K 5% 1/6W
R308	1-249-409-11	CARBON	220 5% 1/6W	R367	1-249-437-11	CARBON	47K 5% 1/6W
R310	1-247-722-11	CARBON	5.6K 5% 1/4W	R368	1-249-428-11	CARBON	8.2K 5% 1/6W
R311	1-249-439-11	CARBON	68K 5% 1/6W	R370	1-249-419-11	CARBON	1.5K 5% 1/6W
R312	1-249-439-11	CARBON	68K 5% 1/6W	R371	1-249-435-11	CARBON	33K 5% 1/6W

**B**

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R372	1-249-441-11	CARBON	100K 5% 1/6W	R438	1-249-431-11	CARBON	15K 5% 1/6W
R373	1-249-435-11	CARBON	33K 5% 1/6W	R439	1-249-418-11	CARBON	1.2K 5% 1/6W
R374	1-249-435-11	CARBON	33K 5% 1/6W	R440	1-249-417-11	CARBON	1K 5% 1/6W
R375	1-249-423-11	CARBON	3.3K 5% 1/6W	R441	1-249-420-11	CARBON	1.8K 5% 1/6W
R377	1-249-409-11	CARBON	220 5% 1/6W	R442	1-249-421-11	CARBON	2.2K 5% 1/6W
R378	1-249-414-11	CARBON	560 5% 1/6W	R443	1-249-408-11	CARBON	180 5% 1/6W
R379	1-249-429-11	CARBON	10K 5% 1/6W	R444	1-249-439-11	CARBON	68K 5% 1/6W
R380	1-249-437-11	CARBON	47K 5% 1/6W	R445	1-249-431-11	CARBON	15K 5% 1/6W
R381	1-249-440-11	CARBON	82K 5% 1/6W	R446	1-249-417-11	CARBON	1K 5% 1/6W
R382	1-249-438-11	CARBON	56K 5% 1/6W	R447	1-249-414-11	CARBON	560 5% 1/6W
R383	1-215-479-00	CARBON	270K 5% 1/6W	R448	1-249-393-11	CARBON	10 5% 1/6W
R384	1-249-425-11	CARBON	4.7K 5% 1/6W	R449	1-249-418-11	CARBON	1.2K 5% 1/6W
R385	1-249-414-11	CARBON	560 5% 1/6W	R450	1-249-419-11	CARBON	1.5K 5% 1/6W
R386	1-249-429-11	CARBON	10K 5% 1/6W	R451	1-249-420-11	CARBON	1.8K 5% 1/6W
R387	1-249-417-11	CARBON	1K 5% 1/6W	R452	1-249-393-11	CARBON	10 5% 1/6W
R388	1-215-483-00	CARBON	390K 5% 1/6W	R453	1-249-419-11	CARBON	1.5K 5% 1/6W
R389	1-249-433-11	CARBON	22K 5% 1/6W	R454	1-249-419-11	CARBON	1.5K 5% 1/6W
R390	1-249-433-11	CARBON	22K 5% 1/6W	R456	1-249-409-11	CARBON	220 5% 1/6W
R391	1-249-437-11	CARBON	47K 5% 1/6W	R457	1-249-435-11	CARBON	33K 5% 1/6W
R392	1-249-431-11	CARBON	15K 5% 1/6W	R458	1-249-425-11	CARBON	4.7K 5% 1/6W
R393	1-249-435-11	CARBON	33K 5% 1/6W	R460	1-249-436-11	CARBON	39K 5% 1/6W
R394	1-249-429-11	CARBON	10K 5% 1/6W	R461	1-249-431-11	CARBON	15K 5% 1/6W
R395	1-247-895-00	CARBON	470K 5% 1/6W	R462	1-249-421-11	CARBON	2.2K 5% 1/6W
R396	1-249-419-11	CARBON	1.5K 5% 1/6W	R463	1-249-422-11	CARBON	2.7K 5% 1/6W
R398	1-249-420-11	CARBON	1.8K 5% 1/6W	R464	1-249-409-11	CARBON	220 5% 1/6W
R401	1-249-412-11	CARBON	390 5% 1/6W	R465	1-249-435-11	CARBON	33K 5% 1/6W
R402	1-247-717-11	CARBON	2.2K 5% 1/4W	R466	1-247-721-11	CARBON	4.7K 5% 1/4W
R403	1-249-427-11	CARBON	6.8K 5% 1/6W	R467	1-215-456-00	CARBON	30K 5% 1/6W
R404	1-249-429-11	CARBON	10K 5% 1/6W	R468	1-249-429-11	CARBON	10K 5% 1/6W
R406	1-249-412-11	CARBON	390 5% 1/6W	R470	1-249-420-11	CARBON	1.8K 5% 1/6W
R410	1-249-422-11	CARBON	2.7K 5% 1/6W	R471	1-249-425-11	CARBON	4.7K 5% 1/6W
R411	1-215-489-00	CARBON	680K 5% 1/6W	R472	1-249-420-11	CARBON	1.8K 5% 1/6W
R412	1-249-417-11	CARBON	1K 5% 1/6W	R473	1-249-425-11	CARBON	4.7K 5% 1/6W
R413	1-249-425-11	CARBON	4.7K 5% 1/6W	R474	1-249-417-11	CARBON	1K 5% 1/6W
R414	1-249-438-11	CARBON	56K 5% 1/6W	R475	1-249-405-11	CARBON	100 5% 1/6W
R415	1-249-429-11	CARBON	10K 5% 1/6W	R476	1-249-416-11	CARBON	820 5% 1/6W
R418	1-247-720-11	CARBON	3.9K 5% 1/4W	R477	1-249-413-11	CARBON	470 5% 1/6W
R419	1-249-429-11	CARBON	10K 5% 1/6W	R478	1-249-421-11	CARBON	2.2K 5% 1/6W
R420	1-249-412-11	CARBON	390 5% 1/6W	R479	1-249-421-11	CARBON	2.2K 5% 1/6W
R421	1-249-438-11	CARBON	56K 5% 1/6W	R480	1-249-429-11	CARBON	10K 5% 1/6W
R422	1-249-427-11	CARBON	6.8K 5% 1/6W	R481	1-249-429-11	CARBON	10K 5% 1/6W
R425	1-249-408-11	CARBON	180 5% 1/6W	R482	1-249-421-11	CARBON	2.2K 5% 1/6W
R426	1-249-435-11	CARBON	33K 5% 1/6W	R483	1-249-421-11	CARBON	2.2K 5% 1/6W
R427	1-249-423-11	CARBON	3.3K 5% 1/6W	R484	1-249-433-11	CARBON	22K 5% 1/6W
R429	1-249-429-11	CARBON	10K 5% 1/6W	R485	1-249-417-11	CARBON	1K 5% 1/6W
R430	1-249-423-11	CARBON	3.3K 5% 1/6W	R486	1-249-435-11	CARBON	33K 5% 1/6W
R431	1-249-425-11	CARBON	4.7K 5% 1/6W	R487	1-249-435-11	CARBON	33K 5% 1/6W
R432	1-249-428-11	CARBON	8.2K 5% 1/6W	R488	1-249-435-11	CARBON	33K 5% 1/6W
R433	1-249-428-11	CARBON	8.2K 5% 1/6W	R1100	1-249-405-11	CARBON	100 5% 1/6W
R434	1-249-418-11	CARBON	1.2K 5% 1/6W	R1101	1-249-437-11	CARBON	47K 5% 1/6W
R435	1-249-417-11	CARBON	1K 5% 1/6W	R1102	1-249-429-11	CARBON	10K 5% 1/6W
R436	1-249-421-11	CARBON	2.2K 5% 1/6W	R1105	1-249-431-11	CARBON	15K 5% 1/6W
R437	1-249-431-11	CARBON	15K 5% 1/6W	R1106	1-249-399-11	CARBON	33 5% 1/6W

The components identified by shading and mark **A** are critical for safety. Replace only with part number specified.

**FA**

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C619	1-129-743-00	FILM 0.022MF	10% 400V	<u>FUSE</u>			
C620	1-124-126-00	ELECT 47MF	20% 16V	F601	1-532-299-11	FUSE, TIME-LAG 5A/250V	
C621	1-130-062-00	FILM 0.0056MF	5% 630V		*1-533-189-11	HOLDER, FUSE; F601	
C622	1-124-344-91	ELECT 22MF	20% 100V	<u>CONNECTOR</u>			
C623	1-161-973-00	CERAMIC 220PF	10% 400V	FA1	*1-506-348-XX	3P PLUG (L)	
C624	1-161-973-00	CERAMIC 220PF	10% 400V	FA2	*1-506-348-XX	3P PLUG (L)	
C632	1-102-002-00	CERAMIC 680PF	10% 500V	FA3	*1-508-765-00	3P PLUG (M)	
C651	1-162-115-00	CERAMIC 330PF	10% 2KV	FA4	*1-508-767-00	5P PLUG	
C652	1-125-294-00	ELECT(BLOCK) 560MF	20% 160V	FA6	*1-508-765-00	3P PLUG (M)	
C653	1-123-364-00	ELECT 1000MF	20% 50V	FA7	*1-566-058-11	PIN, CONNECTOR 6P	
C654	1-123-338-00	ELECT 2200MF	20% 25V	FA9	*1-564-529-11	CONNECTOR, BOARD TO BOARD 5P	
C655	1-123-338-00	ELECT 2200MF	20% 25V	FA10	*1-564-529-11	CONNECTOR, BOARD TO BOARD 5P	
C656	1-162-318-11	CERAMIC 0.001MF	10% 500V	<u>IC</u>			
C658	1-124-126-00	ELECT 47MF	20% 25V	IC602	8-719-800-82	DIODE TLP581	
C659	1-102-030-00	CERAMIC 330PF	10% 500V	IC651	8-759-145-58	IC UPC4558C	
C661	1-123-333-00	ELECT 100MF	20% 25V	<u>COIL</u>			
C662	1-136-332-11	FILM 0.01MF	5% 630V	L601	1-407-365-00	COIL, CHOKE	
C663	1-124-038-00	ELECT 1MF	20% 50V	L652	1-407-780-00	COIL, SPOOK CHOKE	
C664	1-124-038-00	ELECT 1MF	20% 50V	<u>IC LINK</u>			
C666	1-124-123-00	ELECT 100MF	20% 10V	PS651	1-532-675-00	LINK, IC	
C667	1-102-121-00	CERAMIC 0.0022MF	10% 50V	PS652	1-532-686-00	LINK, IC	
C668	1-136-360-51	FILM 0.22MF	20% 250V	PS654	1-532-637-00	LINK, IC	
C669	1-161-738-12	CERAMIC 0.0047MF	20% 400V	<u>TRANSISTOR</u>			
C670	1-161-738-12	CERAMIC 0.0047MF	20% 400V	Q601	8-729-195-82	TRANSISTOR 2SC2958	
C671	1-161-738-12	CERAMIC 0.0047MF	20% 400V	Q602	8-729-802-07	TRANSISTOR 2SD1403-CA	
C672	1-161-738-12	CERAMIC 0.0047MF	20% 400V		3-701-833-01	HEAD, WASHER, TAPPING SCREW; Q602	
C673	1-161-738-12	CERAMIC 0.0047MF	20% 400V		4-365-216-00	SPACER, MICA; Q602	
C674	1-136-360-51	FILM 0.22MF	20% 250V	Q651	8-729-109-53	TRANSISTOR 2SD795A	
C677	1-136-173-00	FILM 0.47MF	5% 50V		*4-347-706-00	HEAT SINK (TR); Q651	
C682	1-130-062-00	FILM 0.0056MF	5% 630V	Q652	8-729-178-54	TRANSISTOR 2SC2785	
C686	1-136-173-00	FILM 0.47MF	5% 50V	<u>RESISTOR</u>			
<u>DIODE</u>				R601	1-217-328-11	WIREWOUND 2.7 10% 7W	F
D601	8-719-503-06	DIODE S3WB60Z		R604	1-247-289-11	CARBON 8.2M 5% 1W	
D602	8-719-100-65	DIODE RD12E-B2		R609	1-215-894-11	METAL OXIDE 2.2K 5% 2W	F
D605	8-719-924-06	DIODE ERC24-06S		R612	1-215-904-11	METAL OXIDE 100K 5% 2W	F
D607	8-719-815-55	DIODE 1S1555		R613	1-215-895-11	METAL OXIDE 3.3K 5% 2W	F
D608	8-719-815-55	DIODE 1S1555		R614	1-216-458-11	METAL OXIDE 1.8K 5% 2W	F
D609	8-719-925-06	DIODE ERC25-06S		R615	1-205-737-00	CEMENTED 30 10% 7W	
D651	8-719-900-26	DIODE ERD29-08J		R623	1-247-718-11	CARBON 2.7K 5% 1/4W	
D653	8-719-300-59	DIODE CTU-12S		R627	1-249-409-11	CARBON 220 5% 1/6W	
D654	8-719-300-59	DIODE CTU-12S		R628	1-215-479-00	CARBON 270K 5% 1/6W	
	*4-347-706-00	HEAT SINK (TR); D654		R629	1-249-427-11	CARBON 6.8K 5% 1/6W	
D655	8-719-000-12	DIODE MC931		R630	1-247-692-11	CARBON 22 5% 1/4W	F
D656	8-719-300-59	DIODE CTU-12S		R631	1-217-352-11	WIREWOUND 390 10% 7W	F
	*4-347-706-00	HEAT SINK (TR); D656		R632	1-217-192-00	WIREWOUND 0.22 10% 2W	F
D658	8-719-110-03	DIODE RD7.5ES-B2		R652	1-216-430-11	METAL OXIDE 390 5% 1W	F
D659	8-719-110-03	DIODE RD7.5ES-B2					
D660	8-719-815-55	DIODE 1S1555					
D661	8-719-815-55	DIODE 1S1555					
D663	8-719-109-93	DIODE RD6.2ES-B2					
D664	8-719-100-65	DIODE RD12E-B2					

The components identified by shading and mark **Δ** are critical for safety. Replace only with part number specified.

FA FC QA

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R653	1-249-425-11	CARBON	4.7K 5% 1/6W			DIODE	
R654	1-216-464-11	METAL OXIDE	18K 5% 2W	F	D603	8-719-815-55	DIODE 1S1555
R662	1-249-436-11	CARBON	39K 5% 1/6W		D604	8-759-157-40	IC UPC574J
R663	1-249-430-11	CARBON	12K 5% 1/6W		D606	8-719-911-19	DIODE 1S5119
R664	1-249-441-11	CARBON	100K 5% 1/6W			CONNECTOR	
R665	1-215-436-00	METAL	4.3K 1% 1/6W		FC1	*1-562-516-11	CONNECTOR, BOARD TO BOARD 5P
R666	1-247-713-11	CARBON	1K 5% 1/4W		FC2	*1-562-516-11	CONNECTOR, BOARD TO BOARD 5P
R667	1-247-703-11	CARBON	180 5% 1/4W			IC	
R669	1-247-720-11	CARBON	3.9K 5% 1/4W		IC601	8-759-100-75	IC UPC1394C
R670	1-249-421-11	CARBON	2.2K 5% 1/6W			TRANSISTOR	
R671	△ 1-205-758-11	CEMENTED	100 10% 10W	F	Q603	8-729-178-54	TRANSISTOR 2SC2785
R673	△ 1-244-945-91	CARBON	1M 5% 1/2W			RESISTOR	
R676	1-205-758-11	CEMENTED	100 10% 10W	F	R605	1-247-891-00	CARBON 330K 5% 1/6W
R677	1-216-346-00	METAL OXIDE	0.56 5% 1W	F	R606	1-249-433-11	CARBON 22K 5% 1/6W
R678	1-247-749-11	CARBON	560 5% 1/2W	F	R608	1-249-421-11	CARBON 2.2K 5% 1/6W
R679	1-215-924-00	METAL OXIDE	15K 5% 3W	F	R611	1-215-457-00	METAL 33K 1% 1/6W
R680	1-217-353-11	WIREWOUND	470 10% 7W	F	R616	1-215-452-00	CARBON 20K 5% 1/6W
R681	1-246-403-75	CARBON	1.2 5% 1/4W		R621	1-249-429-11	CARBON 10K 5% 1/6W
R683	1-216-488-11	METAL OXIDE	18K 5% 3W	F	R622	1-249-433-11	CARBON 22K 5% 1/6W
R684	1-246-403-75	CARBON	1.2 5% 1/4W		R624	1-249-425-11	CARBON 4.7K 5% 1/6W
		VARIABLE RESISTOR			R625	1-249-441-11	CARBON 100K 5% 1/6W
RV651	1-230-230-00	RES, ADJ, CERAMIC CARBON 1K			R626	1-247-712-11	CARBON 820 5% 1/4W
RV652	1-226-702-00	RES, ADJ, METAL GLAZE 2.2K			R633	1-247-887-00	CARBON 220K 5% 1/6W
		TRANSFORMER			R634	1-249-437-11	CARBON 47K 5% 1/6W
T601	△ 1-421-758-11	TRANSFORMER, LINE FILTER (LFT)			R636	1-215-471-00	METAL 120K 1% 1/6W
	△ 1-421-974-11	TRANSFORMER, LINE FILTER (WG ONLY)			R637	1-249-433-11	CARBON 22K 5% 1/6W
T602	△ 1-421-758-11	TRANSFORMER, LINE FILTER (LFT)			R638	1-215-435-00	METAL 3.9K 1% 1/6W
	△ 1-421-974-11	TRANSFORMER, LINE FILTER (WG ONLY)			R639	1-249-425-11	CARBON 4.7K 5% 1/6W
T603	△ 1-437-079-11	TRANSFORMER, HORIZONTAL DRIVE			R674	1-249-440-11	CARBON 82K 5% 1/6W
T605	△ 1-448-931-11	SRT				TERMISTOR	
T607	1-421-975-11	TRANSFORMER, LINE FILTER (WG ONLY)			TH601	△ 1-800-944-11	TERMISTOR TH-4700
		THERMISTOR					*****
TH651	1-800-944-00	THERMISTOR TH-4700			*A-1270-212-A	QA BOARD, COMPLETE (AEP,AUS ONLY)	*****
THP601	△ 1-806-387-11	THERMISTOR (POSITIVE)			*A-1270-223-A	QA BOARD, COMPLETE (WG ONLY)	*****
THP602	△ 1-806-387-11	THERMISTOR (POSITIVE)			1-537-075-11	TERMINAL BOARD, INPUT/OUTPUT	
		*****			1-537-076-11	TERMINAL BOARD, INPUT/OUTPUT	
*1-621-548-11	FC BOARD	*****				CAPACITOR	
3-670-570-41	SPACER, SUPPORT				C1700	1-124-236-00	ELECT 47MF 20% 16V
		CAPACITOR			C1701	1-124-247-00	ELECT 10MF 20% 25V
C611	1-106-220-00	MYLAR	0.1MF 10% 100V		C1702	1-124-247-00	ELECT 10MF 20% 25V
C612	1-106-351-00	MYLAR	0.0022MF 5% 50V		C1703	1-124-236-00	ELECT 47MF 20% 16V
C613	1-123-356-00	ELECT	10MF 20% 16V		C1704	1-124-247-00	ELECT 10MF 20% 25V
C614	1-123-875-91	ELECT	10MF 20% 50V		C1705	1-124-247-00	ELECT 10MF 20% 25V
C615	1-102-074-00	CERAMIC	0.001MF 10% 50V				
C616	1-123-875-91	ELECT	10MF 20% 50V				
C625	1-123-380-00	ELECT	1MF 20% 50V				
C627	1-136-153-00	FILM	0.01MF 5% 50V				
C628	1-102-820-00	CERAMIC	330PF 5% 50V				
C634	1-106-220-00	MYLAR	0.1MF 10% 100V				

The components identified by shading and mark △ are critical for safety. Replace only with part number specified.

**QA**

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C1706	1-124-247-00	ELECT 10MF	20% 25V	R1705	1-247-104-00	CARBON 75 5% 1/4W	
C1707	1-124-247-00	ELECT 10MF	20% 25V	R1706	1-249-417-11	CARBON 1K 5% 1/6W	
C1708	1-124-236-00	ELECT 47MF	20% 16V	R1707	1-215-491-00	CARBON 820K 5% 1/6W	
C1709	1-124-247-00	ELECT 10MF	20% 25V	R1708	1-249-417-11	CARBON 1K 5% 1/6W	
C1710	1-102-965-00	CERAMIC 39PF	5% 50V	R1709	1-215-491-00	CARBON 820K 5% 1/6W	
C1712	1-102-965-00	CERAMIC 39PF	5% 50V	R1710	1-247-104-00	CARBON 75 5% 1/4W	
C1714	1-102-965-00	CERAMIC 39PF	5% 50V	R1711	1-249-414-11	CARBON 560 5% 1/6W	
C1715	1-124-247-00	ELECT 10MF	20% 25V	R1712	1-247-895-00	CARBON 470K 5% 1/6W	
C1716	1-124-247-00	ELECT 10MF	20% 25V	R1713	1-249-414-11	CARBON 560 5% 1/6W	
C1717	1-124-247-00	ELECT 10MF	20% 25V	R1714	1-247-895-00	CARBON 470K 5% 1/6W	
C1718	1-124-247-00	ELECT 10MF	20% 25V	R1715	1-247-104-00	CARBON 75 5% 1/4W	
C1719	1-124-236-00	ELECT 47MF	20% 16V	R1716	1-249-417-11	CARBON 1K 5% 1/6W	
C1720	1-124-236-00	ELECT 47MF	20% 16V	R1717	1-215-491-00	CARBON 820K 5% 1/6W	
C1721	1-124-236-00	ELECT 47MF	20% 16V	R1718	1-247-708-11	CARBON 470 5% 1/4W	
C1722	1-124-236-00	ELECT 47MF	20% 16V	R1719	1-249-408-11	CARBON 180 5% 1/6W	
C1723	1-124-247-00	ELECT 10MF	20% 25V	R1720	1-249-421-11	CARBON 2.2K 5% 1/6W	
C1728	1-102-973-00	CERAMIC 100PF	5% 50V	R1721	1-247-708-11	CARBON 470 5% 1/4W	
C1729	1-102-973-00	CERAMIC 100PF	5% 50V	R1722	1-249-408-11	CARBON 180 5% 1/6W	
C1731	1-102-973-00	CERAMIC 100PF	5% 50V	R1723	1-249-421-11	CARBON 2.2K 5% 1/6W	
C1732	1-102-973-00	CERAMIC 100PF	5% 50V	R1724	1-247-708-11	CARBON 470 5% 1/4W	
C1738	1-102-973-00	CERAMIC 100PF	5% 50V	R1725	1-249-408-11	CARBON 180 5% 1/6W	
C1743	1-102-973-00	CERAMIC 100PF	5% 50V	R1726	1-247-895-00	CARBON 470K 5% 1/6W	
C1744	1-102-973-00	CERAMIC 100PF	5% 50V	R1727	1-247-713-11	CARBON 1K 5% 1/4W	
C1747	1-102-965-00	CERAMIC 39PF	5% 50V	R1728	1-215-491-00	CARBON 820K 5% 1/6W	
C1748	1-102-965-00	CERAMIC 39PF	5% 50V	R1729	1-247-710-11	CARBON 560 5% 1/4W	
C1749	1-102-965-00	CERAMIC 39PF	5% 50V	R1730	1-247-895-00	CARBON 470K 5% 1/6W	
C1750	1-102-965-00	CERAMIC 39PF	5% 50V	R1731	1-247-713-11	CARBON 1K 5% 1/4W	
C1752	1-102-973-00	CERAMIC 100PF	5% 50V	R1732	1-215-491-00	CARBON 820K 5% 1/6W	
C1753	1-102-965-00	CERAMIC 39PF	5% 50V	R1733	1-247-104-00	CARBON 75 5% 1/4W	
<u>DIODE</u>				R1735	1-247-104-00	CARBON 75 5% 1/4W	
D1703	8-719-100-38	DIODE RD6.2E-B2		R1736	1-247-104-00	CARBON 75 5% 1/4W	
D1706	8-719-100-38	DIODE RD6.2E-B2		R1737	1-247-104-00	CARBON 75 5% 1/4W	
D1707	8-719-100-38	DIODE RD6.2E-B2		R1738	1-249-417-11	CARBON 1K 5% 1/6W	
D1708	8-719-100-38	DIODE RD6.2E-B2		R1739	1-247-104-00	CARBON 75 5% 1/4W	
D1709	8-719-100-38	DIODE RD6.2E-B2		R1740	1-249-429-11	CARBON 10K 5% 1/6W	
D1710	8-719-100-38	DIODE RD6.2E-B2		R1742	1-249-412-11	CARBON 390 5% 1/6W	
D1711	8-719-100-38	DIODE RD6.2E-B2		R1743	1-247-713-11	CARBON 1K 5% 1/4W	
<u>JACK</u>				R1744	1-215-491-00	CARBON 820K 5% 1/6W	
J25	1-561-534-41	SOCKET 21P		R1745	1-249-429-11	CARBON 10K 5% 1/6W	
<u>COIL</u>				R1746	1-249-406-11	CARBON 120 5% 1/6W	
L1770	1-408-604-00	MICRO INDUCTOR 12UH (WG ONLY)		R1750	1-249-417-11	CARBON 1K 5% 1/6W	
<u>CONNECTOR</u>				R1751	1-247-104-00	CARBON 75 5% 1/4W	
QA1	*1-566-055-11	PIN, CONNECTOR 3P		R1752	1-249-401-11	CARBON 47 5% 1/6W	
QA2	*1-560-278-00	PLUG, CONNECTOR 3P		R1753	1-249-401-11	CARBON 47 5% 1/6W	
<u>RESISTOR</u>				R1754	1-249-401-11	CARBON 47 5% 1/6W	
R1700	1-247-104-00	CARBON 75 5% 1/4W		R1755	1-249-418-11	CARBON 1.2K 5% 1/6W	
R1701	1-249-417-11	CARBON 1K 5% 1/6W		R1756	1-249-418-11	CARBON 1.2K 5% 1/6W	
R1702	1-215-491-00	CARBON 820K 5% 1/6W		R1760	1-215-483-00	CARBON 390K 5% 1/6W	
R1703	1-249-417-11	CARBON 1K 5% 1/6W		R1761	1-215-483-00	CARBON 390K 5% 1/6W	
R1704	1-215-491-00	CARBON 820K 5% 1/6W		R1762	1-215-483-00	CARBON 390K 5% 1/6W	
				R1763	1-215-483-00	CARBON 390K 5% 1/6W	
				R1768	1-249-406-11	CARBON 120 5% 1/6W	
				R1769	1-247-710-11	CARBON 560 5% 1/4W	

QA QB

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
<u>SWITCH</u>				<u>DIODE</u>			
SW1	1-570-145-11	SWITCH, SLIDE		D1770	8-719-911-19	DIODE 1SS119	
SW2	1-570-145-11	SWITCH, SLIDE		D1771	8-719-911-19	DIODE 1SS119	
SW3	1-570-145-11	SWITCH, SLIDE		D1772	8-719-911-19	DIODE 1SS119	
SW4	1-570-145-11	SWITCH, SLIDE		D1773	8-719-911-19	DIODE 1SS119	
SW5	1-570-145-11	SWITCH, SLIDE		D1774	8-719-911-19	DIODE 1SS119	
*****				D1775	8-719-911-19	DIODE 1SS119	
*A-1270-213-A QB BOARD, COMPLETE				D1776	8-719-911-19	DIODE 1SS119	
*****				D1777	8-719-911-19	DIODE 1SS119	
<u>CAPACITOR</u>				D1780	8-719-911-19	DIODE 1SS119	
C1777	1-102-074-00	CERAMIC	0.001MF	10%	50V	D1781	8-719-911-19
C1778	1-102-074-00	CERAMIC	0.001MF	10%	50V		
C1779	1-124-475-11	ELECT	470MF	20%	16V	D1782	8-719-911-19
C1781	1-101-004-00	CERAMIC	0.01MF		50V	D1783	8-719-931-06
C1788	1-124-247-00	ELECT	10MF	20%	25V	D1784	8-719-110-14
C1789	1-124-247-00	ELECT	10MF	20%	25V	D1787	8-719-109-90
C1790	1-124-236-00	ELECT	47MF	20%	16V	D1788	8-719-911-19
						D1789	8-719-911-19
C1791	1-124-236-00	ELECT	47MF	20%	16V		
C1792	1-102-959-00	CERAMIC	22PF	5%	50V	<u>IC</u>	
C1793	1-101-004-00	CERAMIC	0.01MF		50V	IC1770	8-759-800-65
C1794	1-124-236-00	ELECT	47MF	20%	16V	IC1771	8-759-140-66
C1795	1-101-004-00	CERAMIC	0.01MF		50V	IC1772	8-759-102-37
						IC1773	8-759-102-37
C1799	1-124-471-00	ELECT	1000MF	20%	6.3V	IC1774	8-759-900-86
C1800	1-124-236-00	ELECT	47MF	20%	16V		
C1801	1-124-475-11	ELECT	470MF	20%	16V	IC1775	8-759-901-38
C1802	1-102-971-00	CERAMIC	82PF	5%	50V	IC1776	8-759-900-09
C1803	1-124-471-00	ELECT	1000MF	20%	6.3V		
						<u>COIL</u>	
C1804	1-102-971-00	CERAMIC	82PF	5%	50V	L1770	1-408-239-00
C1806	1-101-361-00	CERAMIC	150PF	5%	50V		
C1807	1-102-111-00	CERAMIC	270PF	10%	50V	<u>TRANSISTOR</u>	
C1808	1-101-004-00	CERAMIC	0.01MF		50V	Q1773	8-729-117-54
C1810	1-124-236-00	ELECT	47MF	20%	16V	Q1774	8-729-178-54
						Q1775	8-729-117-54
C1811	1-124-236-00	ELECT	47MF	20%	16V	Q1776	8-729-178-54
C1813	1-124-236-00	ELECT	47MF	20%	16V	Q1777	8-729-178-54
C1820	1-124-236-00	ELECT	47MF	20%	16V		
C1821	1-101-004-00	CERAMIC	0.01MF		50V	Q1778	8-729-178-54
C1823	1-124-267-11	ELECT	0.1MF	20%	50V	Q1779	8-729-117-54
						Q1780	8-729-117-54
C1824	1-124-267-11	ELECT	0.1MF	20%	50V	Q1781	8-729-178-54
C1825	1-124-267-11	ELECT	0.1MF	20%	50V	Q1784	8-729-900-89
C1827	1-101-880-00	CERAMIC	47PF	5%	50V		
C1828	1-123-611-00	ELECT	1MF	20%	50V	Q1785	8-729-178-54
C1830	1-124-236-00	ELECT	47MF	20%	16V	Q1786	8-729-178-54
						Q1787	8-729-177-43
C1831	1-101-004-00	CERAMIC	0.01MF		50V	Q1788	8-729-117-54
C1832	1-124-236-00	ELECT	47MF	20%	16V	Q1789	8-729-178-54
C1833	1-101-004-00	CERAMIC	0.01MF		50V		
C1834	1-101-004-00	CERAMIC	0.01MF		50V	Q1790	8-729-177-43
C1835	1-124-236-00	ELECT	47MF	20%	16V	Q1791	8-729-900-36
						Q1792	8-729-178-54
C1837	1-124-963-11	ELECT	33MF	20%	16V	Q1793	8-729-117-54
C1838	1-101-880-00	CERAMIC	47PF	5%	50V	Q1794	8-729-178-54
C1839	1-124-236-00	ELECT	47MF	20%	16V		
C1840	1-101-004-00	CERAMIC	0.01MF		50V	Q1795	8-729-178-54
						Q1796	8-729-178-54
						Q1797	8-729-178-54

**QB**

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
Q1798	8-729-117-54	TRANSISTOR 2SA1175		R1785	1-249-441-11	CARBON 100K 5% 1/6W	
Q1799	8-729-178-54	TRANSISTOR 2SC2785		R1786	1-249-441-11	CARBON 100K 5% 1/6W	
Q1802	8-729-900-36	TRANSISTOR DTC124ES		R1787	1-249-433-11	CARBON 22K 5% 1/6W	
Q1803	8-729-178-54	TRANSISTOR 2SC2785		R1788	1-249-413-11	CARBON 470 5% 1/6W	
Q1804	8-729-178-54	TRANSISTOR 2SC2785		R1794	1-247-895-00	CARBON 470K 5% 1/6W	
Q1805	8-729-178-54	TRANSISTOR 2SC2785		R1795	1-249-422-11	CARBON 2.7K 5% 1/6W	
Q1806	8-729-178-54	TRANSISTOR 2SC2785		R1796	1-249-440-11	CARBON 82K 5% 1/6W	
Q1807	8-729-178-54	TRANSISTOR 2SC2785		R1797	1-249-434-11	CARBON 27K 5% 1/6W	
Q1808	8-729-178-54	TRANSISTOR 2SC2785		R1798	1-249-425-11	CARBON 4.7K 5% 1/6W	
Q1809	8-729-178-54	TRANSISTOR 2SC2785		R1799	1-249-419-11	CARBON 1.5K 5% 1/6W	
Q1810	8-729-178-54	TRANSISTOR 2SC2785		R1800	1-249-425-11	CARBON 4.7K 5% 1/6W	
Q1811	8-729-178-54	TRANSISTOR 2SC2785		R1801	1-249-440-11	CARBON 82K 5% 1/6W	
Q1812	8-729-178-54	TRANSISTOR 2SC2785		R1802	1-249-434-11	CARBON 27K 5% 1/6W	
Q1813	8-729-178-54	TRANSISTOR 2SC2785		R1804	1-249-429-11	CARBON 10K 5% 1/6W	
Q1814	8-729-178-54	TRANSISTOR 2SC2785		R1805	1-249-429-11	CARBON 10K 5% 1/6W	
Q1815	8-729-178-54	TRANSISTOR 2SC2785		R1806	1-249-406-11	CARBON 120 5% 1/6W	
Q1816	8-729-178-54	TRANSISTOR 2SC2785		R1807	1-247-849-00	CARBON 5.6K 5% 1/6W	
Q1817	8-729-178-54	TRANSISTOR 2SC2785		R1808	1-247-849-00	CARBON 5.6K 5% 1/6W	
Q1818	8-729-900-36	TRANSISTOR DTC124ES		R1809	1-249-408-11	CARBON 180 5% 1/6W	
Q1819	8-729-900-36	TRANSISTOR DTC124ES		R1810	1-215-422-00	CARBON 1.1K 5% 1/6W	
Q1820	8-729-900-36	TRANSISTOR DTC124ES		R1811	1-249-413-11	CARBON 470 5% 1/6W	
Q1822	8-729-178-54	TRANSISTOR 2SC2785		R1813	1-249-413-11	CARBON 470 5% 1/6W	
Q1823	8-729-178-54	TRANSISTOR 2SC2785		R1814	1-249-413-11	CARBON 470 5% 1/6W	
Q1825	8-729-178-54	TRANSISTOR 2SC2785		R1815	1-249-412-11	CARBON 390 5% 1/6W	
Q1826	8-729-178-54	TRANSISTOR 2SC2785		R1816	1-249-413-11	CARBON 470 5% 1/6W	
Q1827	8-729-178-54	TRANSISTOR 2SC2785		R1817	1-215-422-00	CARBON 1.1K 5% 1/6W	
Q1828	8-729-178-54	TRANSISTOR 2SC2785		R1819	1-249-413-11	CARBON 470 5% 1/6W	
Q1829	8-729-178-54	TRANSISTOR 2SC2785		R1820	1-249-406-11	CARBON 120 5% 1/6W	
Q1830	8-729-177-43	TRANSISTOR 2SD774		R1821	1-249-406-11	CARBON 120 5% 1/6W	
Q1831	8-729-900-36	TRANSISTOR DTC124ES		R1822	1-249-406-11	CARBON 120 5% 1/6W	
Q1832	8-729-178-54	TRANSISTOR 2SC2785		R1823	1-249-406-11	CARBON 120 5% 1/6W	
Q1891	8-729-900-36	TRANSISTOR DTC124ES		R1824	1-247-881-00	CARBON 120K 5% 1/6W	
<u>CONNECTOR</u>				R1825	1-247-881-00	CARBON 120K 5% 1/6W	
QB11	*1-566-058-11	PIN, CONNECTOR 6P		R1826	1-247-881-00	CARBON 120K 5% 1/6W	
QB12	*1-566-056-11	PIN, CONNECTOR 4P		R1827	1-249-429-11	CARBON 10K 5% 1/6W	
QB13	*1-566-056-11	PIN, CONNECTOR 4P		R1828	1-249-417-11	CARBON 1K 5% 1/6W	
QB14	*1-566-054-11	PIN, CONNECTOR 2P		R1829	1-249-429-11	CARBON 10K 5% 1/6W	
QB15	*1-566-057-11	PIN, CONNECTOR 5P		R1830	1-249-429-11	CARBON 10K 5% 1/6W	
QB16	*1-566-056-11	PIN, CONNECTOR 4P		R1831	1-249-417-11	CARBON 1K 5% 1/6W	
QB17	*1-566-059-11	PIN, CONNECTOR 7P		R1832	1-249-429-11	CARBON 10K 5% 1/6W	
<u>RESISTOR</u>				R1833	1-249-429-11	CARBON 10K 5% 1/6W	
R1771	1-249-469-11	CARBON 100K 5% 1/4W		R1834	1-249-417-11	CARBON 1K 5% 1/6W	
R1776	1-249-405-11	CARBON 100 5% 1/6W		R1835	1-249-428-11	CARBON 8.2K 5% 1/6W	
R1777	1-249-405-11	CARBON 100 5% 1/6W		R1836	1-249-422-11	CARBON 2.7K 5% 1/6W	
R1778	1-249-405-11	CARBON 100 5% 1/6W		R1837	1-249-417-11	CARBON 1K 5% 1/6W	
R1779	1-249-441-11	CARBON 100K 5% 1/6W		R1838	1-247-849-00	CARBON 5.6K 5% 1/6W	
R1780	1-249-433-11	CARBON 22K 5% 1/6W		R1839	1-247-849-00	CARBON 5.6K 5% 1/6W	
R1781	1-249-441-11	CARBON 100K 5% 1/6W		R1841	1-249-433-11	CARBON 22K 5% 1/6W	
R1782	1-249-425-11	CARBON 4.7K 5% 1/6W		R1842	1-249-433-11	CARBON 22K 5% 1/6W	
R1783	1-249-469-11	CARBON 100K 5% 1/4W		R1843	1-249-462-11	CARBON 22K 5% 1/4W	
R1784	1-249-433-11	CARBON 22K 5% 1/6W		R1844	1-249-405-11	CARBON 100 5% 1/6W	
				R1845	1-249-433-11	CARBON 22K 5% 1/6W	
				R1846	1-247-714-11	CARBON 1.2K 5% 1/4W	



QB C

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R1847	1-249-437-11	CARBON	47K 5% 1/6W	R1923	1-249-421-11	CARBON	2.2K 5% 1/6W
R1848	1-249-428-11	CARBON	8.2K 5% 1/6W	R1925	1-249-440-11	CARBON	82K 5% 1/6W
R1849	1-249-437-11	CARBON	47K 5% 1/6W	R1926	1-249-440-11	CARBON	82K 5% 1/6W
R1850	1-249-428-11	CARBON	8.2K 5% 1/6W	R1927	1-249-440-11	CARBON	82K 5% 1/6W
R1851	1-249-465-11	CARBON	47K 5% 1/4W	R1928	1-249-405-11	CARBON	100 5% 1/6W
R1852	1-249-428-11	CARBON	8.2K 5% 1/6W	R1929	1-247-849-00	CARBON	5.6K 5% 1/6W
R1853	1-249-416-11	CARBON	820 5% 1/6W	R1930	1-247-714-11	CARBON	1.2K 5% 1/4W
R1854	1-249-416-11	CARBON	820 5% 1/6W	R1931	1-249-417-11	CARBON	1K 5% 1/6W
R1855	1-249-417-11	CARBON	1K 5% 1/6W	R1932	1-249-417-11	CARBON	1K 5% 1/6W
R1856	1-249-417-11	CARBON	1K 5% 1/6W	R1935	1-249-428-11	CARBON	8.2K 5% 1/6W
R1857	1-247-713-11	CARBON	1K 5% 1/4W	R1936	1-249-430-11	CARBON	12K 5% 1/6W
R1858	1-249-433-11	CARBON	22K 5% 1/6W	R1937	1-249-428-11	CARBON	8.2K 5% 1/6W
R1859	1-249-417-11	CARBON	1K 5% 1/6W	R1938	1-249-428-11	CARBON	8.2K 5% 1/6W
R1860	1-249-429-11	CARBON	10K 5% 1/6W	R1939	1-249-428-11	CARBON	8.2K 5% 1/6W
R1861	1-249-417-11	CARBON	1K 5% 1/6W	R1940	1-249-428-11	CARBON	8.2K 5% 1/6W
R1862	1-249-417-11	CARBON	1K 5% 1/6W	R1941	1-249-428-11	CARBON	8.2K 5% 1/6W
R1863	1-249-433-11	CARBON	22K 5% 1/6W	R1942	1-247-695-11	CARBON	39 5% 1/4W
R1864	1-249-417-11	CARBON	1K 5% 1/6W	R1945	1-249-428-11	CARBON	8.2K 5% 1/6W
R1865	1-249-425-11	CARBON	4.7K 5% 1/6W	R1950	1-249-428-11	CARBON	8.2K 5% 1/6W
R1866	1-249-412-11	CARBON	390 5% 1/6W	R1951	1-249-429-11	CARBON	10K 5% 1/6W
R1867	1-249-417-11	CARBON	1K 5% 1/6W	R1952	1-215-865-11	METAL OXIDE	220 5% 1W F
R1868	1-249-412-11	CARBON	390 5% 1/6W	R1953	1-249-423-11	CARBON	3.3K 5% 1/6W
R1869	1-249-421-11	CARBON	2.2K 5% 1/6W	R1955	1-249-435-11	CARBON	33K 5% 1/6W
R1870	1-249-421-11	CARBON	2.2K 5% 1/6W	R1956	1-249-434-11	CARBON	27K 5% 1/6W
R1871	1-249-421-11	CARBON	2.2K 5% 1/6W	R1965	1-247-712-11	CARBON	820 5% 1/4W
R1872	1-249-433-11	CARBON	22K 5% 1/6W	R1966	1-247-712-11	CARBON	820 5% 1/4W
R1873	1-249-429-11	CARBON	10K 5% 1/6W	R1967	1-247-712-11	CARBON	820 5% 1/4W
R1874	1-249-413-11	CARBON	470 5% 1/6W	R1968	1-247-881-00	CARBON	120K 5% 1/6W
R1875	1-215-432-00	CARBON	3K 5% 1/6W	R1969	1-249-440-11	CARBON	82K 5% 1/6W
R1876	1-249-420-11	CARBON	1.8K 5% 1/6W	R1971	1-249-417-11	CARBON	1K 5% 1/6W
R1877	1-249-429-11	CARBON	10K 5% 1/6W	R1972	1-249-417-11	CARBON	1K 5% 1/6W
R1879	1-249-469-11	CARBON	100K 5% 1/4W	R1973	1-249-417-11	CARBON	1K 5% 1/6W
R1880	1-249-417-11	CARBON	1K 5% 1/6W	R1974	1-247-713-11	CARBON	1K 5% 1/4W
R1881	1-249-422-11	CARBON	2.7K 5% 1/6W	*****			
R1882	1-249-417-11	CARBON	1K 5% 1/6W	*A-1330-801-A C BOARD, COMPLETE			
R1883	1-249-433-11	CARBON	22K 5% 1/6W	*****			
R1884	1-249-417-11	CARBON	1K 5% 1/6W	1-526-798-21 SOCKET, CRT			
R1885	1-249-416-11	CARBON	820 5% 1/6W	*4-379-160-01 COVER (REAR LID), CV			
R1886	1-249-417-11	CARBON	1K 5% 1/6W	*4-379-167-01 COVER (MAIN), CV			
R1887	1-247-715-11	CARBON	1.5K 5% 1/4W	CONNECTOR			
R1888	1-249-417-11	CARBON	1K 5% 1/6W	C1	*1-506-371-00	2P PLUG (L)	
R1892	1-249-415-11	CARBON	680 5% 1/6W	C2	*1-508-765-00	3P PLUG (M)	
R1893	1-249-433-11	CARBON	22K 5% 1/6W	C3	*1-508-765-00	3P PLUG (M)	
R1894	1-249-428-11	CARBON	8.2K 5% 1/6W	C4	*1-566-055-11	PIN, CONNECTOR 3P	
R1896	1-249-415-11	CARBON	680 5% 1/6W	C5	*1-566-061-11	PIN, CONNECTOR 9P	
R1898	1-247-849-00	CARBON	5.6K 5% 1/6W	C8	*1-508-784-00	1P PLUG	
R1899	1-247-849-00	CARBON	5.6K 5% 1/6W	CAPACITOR			
R1901	1-249-429-11	CARBON	10K 5% 1/6W	C701	1-162-116-00	CERAMIC	680PF 10% 2KV
R1902	1-249-417-11	CARBON	1K 5% 1/6W	C702	1-129-714-00	FILM	0.01MF 10% 630V
R1903	1-249-412-11	CARBON	390 5% 1/6W	C703	1-123-356-00	ELECT	10MF 20% 50V
R1921	1-249-424-11	CARBON	3.9K 5% 1/6W	C704	1-123-948-00	ELECT	22MF 20% 250V
R1922	1-249-424-11	CARBON	3.9K 5% 1/6W	C705	1-108-692-81	MYLAR	0.01MF 10% 200V

**C**

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C706	1-129-751-00	FILM 0.1MF	10% 400V	<b>RESISTOR</b>			
C707	1-102-116-00	CERAMIC 680PF	10% 50V	R701	1-216-397-11	METAL OXIDE 4.7 5% 3W	F
C708	1-102-116-00	CERAMIC 680PF	10% 50V	R702	1-202-848-00	SOLID 680K 10% 1/2W	
C709	1-102-116-00	CERAMIC 680PF	10% 50V	R703	1-202-838-00	SOLID 100K 10% 1/2W	
C710	1-102-116-00	CERAMIC 680PF	10% 50V	R704	1-202-846-00	SOLID 470K 10% 1/2W	
C711	1-123-356-00	ELECT 10MF	20% 25V	R705	1-202-549-00	SOLID 100 5% 1/2W	
C712	1-102-114-00	CERAMIC 470PF	10% 50V	R706	1-202-838-00	SOLID 100K 10% 1/2W	
C713	1-102-116-00	CERAMIC 680PF	10% 50V	R707	1-202-842-11	SOLID 220K 10% 1/2W	
C714	1-162-622-11	CERAMIC 330PF	10% 6.3KV	R708	1-202-818-00	SOLID 1K 10% 1/2W	
C715	1-102-125-00	CERAMIC 0.0047MF	10% 50V	R709	1-202-818-00	SOLID 1K 10% 1/2W	
C718	1-102-074-00	CERAMIC 0.001MF	10% 50V	R710	1-202-818-00	SOLID 1K 10% 1/2W	
C719	1-102-050-00	CERAMIC 0.01MF	500V	R711	1-202-837-00	SOLID 82K 10% 1/2W	
<b>DIODE</b>				R712	1-202-842-11	SOLID 220K 10% 1/2W	
D701	8-719-911-19	DIODE 1SS119		R713	1-216-486-00	METAL OXIDE 8.2K 5% 3W	F
D702	8-719-911-19	DIODE 1SS119		R714	1-249-409-11	CARBON 220 5% 1/6W	
D703	8-719-911-19	DIODE 1SS119		R716	1-216-486-00	METAL OXIDE 8.2K 5% 3W	F
D704	8-719-911-19	DIODE 1SS119		R717	1-249-409-11	CARBON 220 5% 1/6W	
D705	8-719-911-19	DIODE 1SS119		R720	1-216-486-00	METAL OXIDE 8.2K 5% 3W	F
D706	8-719-911-19	DIODE 1SS119		R721	1-249-409-11	CARBON 220 5% 1/6W	
D707	8-719-911-19	DIODE 1SS119		R722	1-249-405-11	CARBON 100 5% 1/6W	
D708	8-719-911-19	DIODE 1SS119		R723	1-249-405-11	CARBON 100 5% 1/6W	
D709	8-719-911-19	DIODE 1SS119		R724	1-249-405-11	CARBON 100 5% 1/6W	
D710	8-719-901-83	DIODE 1SS83		R725	1-249-429-11	CARBON 10K 5% 1/6W	
D711	8-719-901-83	DIODE 1SS83		R726	1-249-409-11	CARBON 220 5% 1/6W	
D712	8-719-901-83	DIODE 1SS83		R727	1-249-429-11	CARBON 10K 5% 1/6W	
D713	8-719-901-83	DIODE 1SS83		R728	1-215-404-00	CARBON 200 5% 1/6W	
<b>COIL</b>				R729	1-249-385-11	CARBON 2.2 5% 1/6W	
L701	1-407-711-00	MICRO INDUCTOR 330UH		R730	1-249-408-11	CARBON 180 5% 1/6W	
L702	1-407-705-00	MICRO INDUCTOR 100UH		R731	1-247-704-11	CARBON 220 5% 1/4W	F
L703	1-407-703-00	MICRO INDUCTOR 68UH		R732	1-247-704-11	CARBON 220 5% 1/4W	F
L704	1-408-442-11	MICRO INDUCTOR 10UH		R733	1-247-704-11	CARBON 220 5% 1/4W	F
L705	1-408-404-00	MICRO INDUCTOR 3.9UH		R734	1-247-717-11	CARBON 2.2K 5% 1/4W	
L706	1-407-705-00	MICRO INDUCTOR 100UH		R735	1-247-138-00	CARBON 2K 5% 1/4W	
L707	1-408-434-00	MICRO INDUCTOR 2.2UH		R736	1-247-717-11	CARBON 2.2K 5% 1/4W	
<b>TRANSISTOR</b>				R737	1-249-441-11	CARBON 100K 5% 1/6W	
Q701	8-729-326-11	TRANSISTOR 2SC2611		R739	1-247-887-00	CARBON 220K 5% 1/6W	
Q702	8-729-178-54	TRANSISTOR 2SC2785		R740	1-215-902-11	METAL OXIDE 47K 5% 2W	F
Q703	8-729-200-17	TRANSISTOR 2SA1091		R741	1-249-438-11	CARBON 56K 5% 1/6W	
Q704	8-729-326-11	TRANSISTOR 2SC2611		R742	1-249-429-11	CARBON 10K 5% 1/6W	F
Q705	8-729-178-54	TRANSISTOR 2SC2785		R743	1-249-429-11	CARBON 10K 5% 1/6W	F
Q706	8-729-200-17	TRANSISTOR 2SA1091		R744	1-247-725-11	CARBON 10K 5% 1/4W	F
Q707	8-729-200-17	TRANSISTOR 2SA1091		R745	1-247-713-11	CARBON 1K 5% 1/4W	F
Q708	8-729-326-11	TRANSISTOR 2SC2611		R746	1-215-879-51	METAL OXIDE 47K 5% 1W	F
Q709	8-729-178-54	TRANSISTOR 2SC2785		R747	1-247-725-11	CARBON 10K 5% 1/4W	F
Q710	8-729-255-12	TRANSISTOR 2SC2551		R775	1-247-779-00	CARBON 6.8 5% 1/6W	
Q712	8-729-255-12	TRANSISTOR 2SC2551		R776	1-247-779-00	CARBON 6.8 5% 1/6W	
Q714	8-729-200-17	TRANSISTOR 2SA1091		R777	1-249-441-11	CARBON 100K 5% 1/6W	
Q715	8-729-200-17	TRANSISTOR 2SA1091		R799	1-202-842-11	SOLID 220K 10% 1/2W	
Q716	8-729-200-17	TRANSISTOR 2SA1091		<b>VARIABLE RESISTOR</b>			
				RV701	1-226-114-00	RES, ADJ, METAL GLAZE 2.2M	
				RV702	1-230-619-11	RES, ADJ, METAL GLAZE 110M	



Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
RV703	1-228-731-00	RES, ADJ, CERAMIC CARBON 470K		C564	1-102-244-00	CERAMIC 220PF 10% 500V	
RV705	1-228-729-00	RES, ADJ, CERAMIC CARBON 220K		C566	1-106-367-00	MYLAR 0.01MF 10% 100V	
RV706	1-228-724-00	RES, ADJ, CERAMIC CARBON 10K		C568	1-106-212-00	MYLAR 0.047MF 10% 100V	
*****				C570	1-102-212-00	CERAMIC 820PF 10% 500V	
*****				C571	1-123-349-00	ELECT 1000MF 20% 35V	
*****				C572	1-102-244-00	CERAMIC 220PF 10% 500V	
*****				C573	1-123-935-00	ELECT 33MF 20% 160V	
*****				C574	1-106-369-00	MYLAR 0.012MF 10% 200V	
*****				C575	1-123-024-00	ELECT 33MF 160V	
*****				C576	1-162-114-00	CERAMIC 0.0047MF 2KV	
*****				C578	1-124-902-00	ELECT 0.47MF 20% 50V	
*****				C579	1-102-030-00	CERAMIC 330PF 10% 500V	
*****				C580	1-108-689-11	MYLAR 0.0056MF 10% 200V	
*****				C581	1-136-512-11	FILM 0.0106MF 3% 1.4KV	
*****				C582	1-162-135-11	CERAMIC 560PF 10% 2KV	
*****				C583	1-106-367-00	MYLAR 0.01MF 10% 100V	
*****				C586	1-162-115-00	CERAMIC 330PF 10% 2KV	
*****				C587	1-129-747-00	FILM 0.047MF 10% 400V	
*****				C588	1-136-513-11	FILM 0.82MF 5% 200V	
*****				C589	1-136-116-00	FILM 1MF 5% 200V	
*****				C590	1-123-356-00	ELECT 10MF 20% 25V	
*****				C593	1-124-555-00	ELECT 1000MF 20% 16V	
*****				C598	1-123-332-00	ELECT 47MF 20% 16V	
*****				C1510	1-106-367-00	MYLAR 0.01MF 10% 100V	
*****				C1515	1-124-477-11	ELECT 47MF 20% 25V	
*****				C1516	1-124-927-11	ELECT 4.7MF 20% 50V	
*****				C1517	1-124-902-00	ELECT 0.47MF 20% 50V	
*****				C1518	1-108-630-91	MYLAR 0.022MF 10% 100V	
*****				C1519	1-124-791-11	ELECT 1MF 20% 50V	
*****				C1520	1-123-875-91	ELECT 10MF 20% 50V	
*****				C1521	1-108-855-00	MYLAR 0.33MF 10% 50V	
*****				C1522	1-108-837-00	MYLAR 0.01MF 10% 50V	
*****				C1524	1-106-172-00	MYLAR 0.001MF 5% 50V	
*****				C1525	1-124-927-11	ELECT 4.7MF 20% 50V	
*****				C1526	1-102-971-00	CERAMIC 82PF 5% 50V	
*****				C1527	1-123-356-00	ELECT 10MF 20% 50V	
*****				C1528	1-123-356-00	ELECT 10MF 20% 50V	
*****				C1529	1-124-791-11	ELECT 1MF 20% 50V	
*****				C1531	1-102-231-11	CERAMIC 47PF 10% 500V	
*****				C1532	1-124-445-00	ELECT 100MF 20% 16V	
*****				C1537	1-108-845-00	MYLAR 0.047MF 10% 50V	
*****				CONNECTOR			
*****				D1	*1-508-766-00	4P PLUG (M)	
*****				D2	*1-566-055-11	PIN, CONNECTOR 3P	
*****				D3	*1-566-054-11	PIN, CONNECTOR 2P	
*****				D4	*1-508-767-00	5P PLUG	
*****				D5	*1-508-765-00	3P PLUG (M)	
*****				D6	*1-564-038-00	CONNECTOR PLUG, DY (MINI) 6P	
*****				D7	*1-566-056-11	PIN, CONNECTOR 4P	
*****				D9	*1-566-055-11	PIN, CONNECTOR 3P	
*****				D10	*1-508-766-00	4P PLUG (M)	
*****				D11	*1-508-765-00	3P PLUG (M)	

**D**

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
D14	*1-566-054-11	PIN, CONNECTOR 2P		L564	1-407-717-00	MICRO INDUCTOR 1MMH	
				L1510	1-459-115-00	COIL, DCC-H	
		<u>DIODE</u>				<u>NEON LAMP</u>	
D501	8-719-911-19	DIODE 1SS119		NL601	1-519-237-11	LAMP, NEON	
D502	8-719-911-55	DIODE U05G				<u>TRANSISTOR</u>	
D504	8-719-911-19	DIODE 1SS119		Q505	8-729-178-54	TRANSISTOR 2SC2785	
D505	8-719-911-19	DIODE 1SS119		Q506	8-729-178-54	TRANSISTOR 2SC2785	
D507	8-719-100-35	DIODE RD5.6E-B2		Q507	8-729-178-54	TRANSISTOR 2SC2785	
				Q508	8-729-117-54	TRANSISTOR 2SA1175	
D509	8-719-110-06	DIODE RD8.2ES-B1		Q551	8-729-168-82	TRANSISTOR 2SC2688	
D510	8-719-911-19	DIODE 1SS119		Q552	8-729-203-80	TRANSISTOR 2SD1555-LB-S1	
D551	8-719-911-55	DIODE U05G			4-367-513-00	SPACER, MICA; Q552	
D554	8-719-300-65	DIODE ES1F		Q553	8-729-313-42	TRANSISTOR 2SD1134	
D557	8-719-918-77	DIODE V19G		Q1510	8-729-117-54	TRANSISTOR 2SA1175	
				Q1511	8-729-178-54	TRANSISTOR 2SC2785	
D558	8-719-300-76	DIODE RH1A		Q1512	8-729-900-36	TRANSISTOR DTC124ES	
D560	8-719-305-15	DIODE GH3F		Q1513	8-729-900-63	TRANSISTOR DTA124ES	
D561	8-719-928-08	DIODE ERD28-08S		Q1514	8-729-900-36	TRANSISTOR DTC124ES	
D562	8-719-300-65	DIODE ES1F		Q1515	8-729-900-36	TRANSISTOR DTC124ES	
D1510	8-719-911-55	DIODE U05G		Q1516	8-729-105-73	TRANSISTOR 2SK523-L2	
				Q1517	8-729-900-36	TRANSISTOR DTC124ES	
D1511	8-719-911-19	DIODE 1SS119		Q1518	8-729-900-36	TRANSISTOR DTC124ES	
D1512	8-719-911-19	DIODE 1SS119		Q1519	8-729-178-54	TRANSISTOR 2SC2785	
D1513	8-719-911-55	DIODE U05G		Q1520	8-729-178-54	TRANSISTOR 2SC2785	
D1514	8-719-911-55	DIODE U05G		Q1521	8-729-117-54	TRANSISTOR 2SA1175	
D1516	8-759-157-40	DIODE UPC574J		Q1522	8-729-177-43	TRANSISTOR 2SD774	
D1517	8-719-918-77	DIODE V19G		Q1523	8-729-103-43	TRANSISTOR 2SB734	
D1518	8-719-918-77	DIODE V19G				<u>RESISTOR</u>	
D1521	8-719-911-19	DIODE 1SS119		R501	1-247-725-11	CARBON 10K 5% 1/4W	
D1522	8-719-000-12	DIODE MC931		R503	1-249-422-11	CARBON 2.7K 5% 1/6W	
		<u>FUSE</u>		R504	1-249-411-11	CARBON 330 5% 1/6W	
F501	A.1-532-285-11	FUSE, TIME-LAG 1.25A/250V		R505	1-247-702-11	CARBON 150 5% 1/4W	
	*1-533-189-11	HOLDER, FUSE; F501		R506	1-247-700-11	CARBON 100 5% 1/4W	
		<u>IC</u>		R507	1-246-536-00	CARBON 430K 5% 1/4W	
IC501	8-759-100-60	IC UPC1377C		R508	1-249-462-11	CARBON 22K 5% 1/4W	
IC502	8-759-170-12	IC UPC78M12H		R509	1-249-433-11	CARBON 22K 5% 1/6W	
IC551	8-759-105-82	IC UPC1378H-P		R510	1-247-881-00	CARBON 120K 5% 1/6W	
	3-701-833-01	HEAD, WASHER, TAPPING SCREW; IC551		R511	1-247-868-00	CARBON 36K 5% 1/6W	
IC552	8-759-145-58	IC UPC4558C		R512	1-249-411-11	CARBON 330 5% 1/6W	
				R513	1-249-468-11	CARBON 82K 5% 1/4W	
IC1510	8-759-145-58	IC UPC4558C		R514	1-247-723-11	CARBON 6.8K 5% 1/4W	
IC1511	8-759-145-58	IC UPC4558C		R515	1-249-459-11	CARBON 12K 5% 1/4W	
IC1512	8-759-909-70	IC CX23025		R516	1-249-435-11	CARBON 33K 5% 1/6W	
		<u>COIL</u>		R517	1-249-407-11	CARBON 150 5% 1/6W	
L551	1-459-678-11	HLC		R518	1-247-701-11	CARBON 120 5% 1/4W	F
L552	1-459-390-00	COIL (WITH CORE)		R519	1-247-849-00	CARBON 5.6K 5% 1/6W	
L555	1-408-227-00	MICRO INDUCTOR 470UH		R520	1-249-419-11	CARBON 1.5K 5% 1/6W	
L556	1-407-699-00	MICRO INDUCTOR 33UH		R521	1-249-417-11	CARBON 1K 5% 1/6W	
L557	1-459-407-00	COIL, FERRITE CHOKE		R522	1-249-439-11	CARBON 68K 5% 1/6W	
L558	1-407-365-00	COIL, CHOKE					
L559	1-407-364-00	COIL, SPOOK CHOKE 3.3UH					
L560	1-407-695-00	MICRO INDUCTOR 15UH					
L562	1-408-239-00	MICRO INDUCTOR 4.7MMH					
L563	1-459-075-00	COIL, DYNAMIC CONVERSION CHOKE					

The components identified by shading and mark **A** are critical for safety. Replace only with part number specified.

D

D

HD

HC

K

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R523	1-215-447-00	METAL	12K 1% 1/6W	R583	1-249-433-11	CARBON	22K 5% 1/6W	R1547	1-249-429-11	CARBON	10K 5% 1/6W	*A-1375-066-A HC BOARD, COMPLETE			
R524	1-214-756-00	METAL	13K 1% 1/4W	R584	1-246-511-00	CARBON	39K 5% 1/4W	R1548	1-215-493-00	CARBON	1M 5% 1/6W	*****			
R525	1-249-429-11	CARBON	10K 5% 1/6W	R585	1-247-719-11	CARBON	3.3K 5% 1/4W	R1550	1-247-895-00	CARBON	470K 5% 1/6W	CAPACITOR			
R526	1-215-876-00	METAL OXIDE	15K 5% 1W	R586	1-249-428-11	CARBON	8.2K 5% 1/6W	R1551	1-249-437-11	CARBON	47K 5% 1/6W	C982	1-130-023-00	FILM	0.0027MF 5% 50V
R527	1-249-412-11	CARBON	390 5% 1/6W	R587	1-246-523-00	CARBON	120K 5% 1/4W	R1552	1-247-849-00	CARBON	5.6K 5% 1/6W	C983	1-130-028-00	FILM	0.0068MF 5% 50V
R528	1-249-405-11	CARBON	100 5% 1/6W	R588	1-249-422-11	CARBON	2.7K 5% 1/6W	R1553	1-247-881-00	CARBON	120K 5% 1/6W	C984	1-108-837-00	MYLAR	0.01MF 10% 50V
R529	1-214-743-00	METAL	3.9K 1% 1/4W	R589	1-249-424-11	CARBON	3.9K 5% 1/6W	R1558	1-247-887-00	CARBON	220K 5% 1/6W	C985	1-123-617-00	ELECT	10MF 20% 16V
R530	1-214-753-00	METAL	10K 1% 1/4W	R590	1-249-421-11	CARBON	2.2K 5% 1/6W	R1559	1-249-441-11	CARBON	100K 5% 1/6W	C986	1-123-356-00	ELECT	10MF 20% 25V
R534	1-214-747-00	METAL	5.6K 1% 1/4W	R592	1-215-871-11	METAL OXIDE	2.2K 5% 1W	R1560	1-249-419-11	CARBON	1.5K 5% 1/6W	DIODE			
R535	1-249-424-11	CARBON	3.9K 5% 1/6W	R593	1-249-417-11	CARBON	1K 5% 1/6W	R1561	1-249-435-11	CARBON	33K 5% 1/6W	D971	8-719-109-85	DIODE	RD5.1ES-B2
R536	1-247-849-00	CARBON	5.6K 5% 1/6W	R594	1-249-435-11	CARBON	33K 5% 1/6W	R1562	1-249-440-11	CARBON	82K 5% 1/6W	CONNECTOR			
R537	1-249-429-11	CARBON	10K 5% 1/6W	R595	1-249-421-11	CARBON	2.2K 5% 1/6W	R1563	1-249-409-11	CARBON	220 5% 1/6W	HC1	*1-566-057-11	PIN, CONNECTOR	5P
R538	1-216-350-11	METAL OXIDE	1.2 5% 1W	R596	1-249-420-11	CARBON	1.8K 5% 1/6W	R1565	1-216-349-00	METAL OXIDE	1 5% 1W	HC2	*1-566-056-11	PIN, CONNECTOR	4P
R539	1-249-413-11	CARBON	470 5% 1/6W	R597	1-249-409-11	CARBON	220 5% 1/6W	R1566	1-216-430-11	METAL OXIDE	390 5% 1W	HC3	*1-566-054-11	PIN, CONNECTOR	2P
R540	1-247-872-00	CARBON	51K 5% 1/6W	R598	1-246-525-00	CARBON	150K 5% 1/4W	R1567	1-216-430-11	METAL OXIDE	390 5% 1W	HC4	*1-566-054-11	PIN, CONNECTOR	2P
R541	1-249-429-11	CARBON	10K 5% 1/6W	R599	1-249-431-11	CARBON	15K 5% 1/6W	R1568	1-249-419-11	CARBON	1.5K 5% 1/6W	IC			
R542	1-214-779-00	METAL	120K 1% 1/4W	R1501	1-215-469-00	METAL	100K 1% 1/6W	R1569	1-249-417-11	CARBON	1K 5% 1/6W	IC985	8-759-933-23	IC	BA236
R543	1-215-493-00	CARBON	1M 5% 1/6W	R1502	1-215-451-00	METAL	18K 1% 1/6W	R1570	1-249-382-11	CARBON	1.2 5% 1/6W	RESISTOR			
R544	1-214-781-00	METAL	150K 1% 1/4W	R1503	1-247-722-11	CARBON	5.6K 5% 1/4W	R1571	1-249-382-11	CARBON	1.2 5% 1/6W	R982	1-249-429-11	CARBON	10K 5% 1/6W
R545	1-214-765-00	METAL	33K 1% 1/4W	R1505	1-215-869-11	METAL OXIDE	1K 5% 1W	R1572	1-247-883-00	CARBON	150K 5% 1/6W	R983	1-249-417-11	CARBON	1K 5% 1/6W
R546	1-249-424-11	CARBON	3.9K 5% 1/6W	R1510	1-249-429-11	CARBON	10K 5% 1/6W	R1573	1-247-773-00	CARBON	3.9 5% 1/6W	R984	1-249-429-11	CARBON	10K 5% 1/6W
R547	1-249-429-11	CARBON	10K 5% 1/6W	R1511	1-249-437-11	CARBON	47K 5% 1/6W	R1583	1-249-429-11	CARBON	10K 5% 1/6W	R985	1-249-417-11	CARBON	1K 5% 1/6W
R548	1-249-421-11	CARBON	2.2K 5% 1/6W	R1515	1-249-429-11	CARBON	10K 5% 1/6W	R1584	1-249-413-11	CARBON	470 5% 1/6W	R986	1-249-429-11	CARBON	10K 5% 1/6W
R549	1-247-704-11	CARBON	220 5% 1/4W	R1516	1-249-433-11	CARBON	22K 5% 1/6W	R1585	1-249-417-11	CARBON	1K 5% 1/6W	R988	1-249-405-11	CARBON	100 5% 1/6W
R551	1-214-681-00	METAL	10 1% 1/4W	R1517	1-249-430-11	CARBON	12K 5% 1/6W	R1586	1-247-713-11	CARBON	1K 5% 1/4W	R989	1-249-417-11	CARBON	1K 5% 1/6W
R553	1-247-746-11	CARBON	390 5% 1/2W	R1518	1-249-425-11	CARBON	4.7K 5% 1/6W	R1587	1-249-424-11	CARBON	3.9K 5% 1/6W	R990	1-249-432-11	CARBON	18K 5% 1/6W
R554	1-246-533-00	CARBON	330K 5% 1/4W	R1519	1-249-429-11	CARBON	10K 5% 1/6W	R1588	1-249-416-11	CARBON	820 5% 1/6W	R991	1-249-408-11	CARBON	180 5% 1/6W
R555	1-249-431-11	CARBON	15K 5% 1/6W	R1520	1-247-895-00	CARBON	470K 5% 1/6W	VARIABLE RESISTOR				R992	1-249-427-11	CARBON	6.8K 5% 1/6W
R556	1-246-523-00	CARBON	120K 5% 1/4W	R1521	1-249-429-11	CARBON	10K 5% 1/6W	RV501	1-228-723-00	RES, ADJ, CERAMIC CARBON	4.7K	R993	1-249-418-11	CARBON	1.2K 5% 1/6W
R557	1-249-432-11	CARBON	18K 5% 1/6W	R1522	1-249-409-11	CARBON	220 5% 1/6W	RV503	1-228-717-00	RES, ADJ, CERAMIC CARBON	220	R994	1-249-420-11	CARBON	1.8K 5% 1/6W
R558	1-249-437-11	CARBON	47K 5% 1/6W	R1523	1-249-441-11	CARBON	100K 5% 1/6W	RV509	1-224-249-XX	RES, ADJ, METAL GLAZE	1K	VARIABLE RESISTOR			
R559	1-215-479-00	CARBON	270K 5% 1/6W	R1524	1-249-437-11	CARBON	47K 5% 1/6W	RV552	1-228-725-00	RES, ADJ, CERAMIC CARBON	22K	RV982	1-237-349-11	RES, VAR, CARBON	10K
R560	1-247-895-00	CARBON	470K 5% 1/6W	R1525	1-249-425-11	CARBON	4.7K 5% 1/6W	RV553	1-228-720-00	RES, ADJ, CERAMIC CARBON	1K	RV983	1-237-712-11	RES, VAR, CARBON	10K
R561	1-249-429-11	CARBON	10K 5% 1/6W	R1526	1-249-435-11	CARBON	33K 5% 1/6W	SPARK GAP				RV984	1-237-712-11	RES, VAR, CARBON	10K
R562	1-249-425-11	CARBON	4.7K 5% 1/6W	R1527	1-249-421-11	CARBON	2.2K 5% 1/6W	SG551	1-519-063-XX	DISCHARGING GAP		RV985	1-237-350-11	RES, VAR, CARBON	20K
R564	1-247-719-11	CARBON	3.3K 5% 1/4W	R1528	1-249-438-11	CARBON	56K 5% 1/6W	TRANSFORMER				RV986	1-230-631-11	RES, ADJ, CARBON	22K
R565	1-216-428-00	METAL OXIDE	180 5% 1W	R1529	1-249-431-11	CARBON	15K 5% 1/6W	T552	1-437-090-00	HDT		RV987	1-237-348-11	RES, VAR, CARBON	5K
R567	1-249-429-11	CARBON	10K 5% 1/6W	R1530	1-249-423-11	CARBON	3.3K 5% 1/6W	T553	1-437-191-11	HCT		*****			
R568	1-247-715-11	CARBON	1.5K 5% 1/4W	R1532	1-249-431-11	CARBON	15K 5% 1/6W	THERMISTOR				*A-1389-865-A K BOARD, COMPLETE			
R569	1-249-410-11	CARBON	270 5% 1/6W	R1533	1-249-437-11	CARBON	47K 5% 1/6W	TH501	1-806-213-00	THERMISTOR		*****			
R570	1-249-417-11	CARBON	1K 5% 1/6W	R1534	1-249-437-11	CARBON	47K 5% 1/6W	TH551	1-800-944-00	THERMISTOR TH-4700		CAPACITOR			
R571	1-247-711-11	CARBON	680 5% 1/4W	R1535	1-249-413-11	CARBON	470 5% 1/6W	*****				C201	1-124-902-00	ELECT	0.47MF 20% 50V
R572	1-249-418-11	CARBON	1.2K 5% 1/6W	R1536	1-249-418-11	CARBON	1.2K 5% 1/6W	*1-621-541-11	HD BOARD			C202	1-124-902-00	ELECT	0.47MF 20% 50V
R573	1-216-445-11	METAL OXIDE	12 5% 2W	R1537	1-249-423-11	CARBON	3.3K 5% 1/6W	*****				C203	1-123-332-00	ELECT	47MF 20% 16V
R574	1-249-409-11	CARBON	220 5% 1/6W	R1538	1-215-480-00	CARBON	300K 5% 1/6W	SWITCH							
R575	1-247-725-11	CARBON	10K 5% 1/4W	R1539	1-249-429-11	CARBON	10K 5% 1/6W	S996	1-570-145-11	SWITCH, SLIDE					
R576	1-249-427-11	CARBON	6.8K 5% 1/6W	R1540	1-216-510-11	METAL OXIDE	8.2K 5% 5W	S997	1-570-145-11	SWITCH, SLIDE					
R577	1-249-429-11	CARBON	10K 5% 1/6W	R1541	1-249-429-11	CARBON	10K 5% 1/6W								
R578	1-249-411-11	CARBON	330 5% 1/6W	R1542	1-249-429-11	CARBON	10K 5% 1/6W								
R579	1-247-719-11	CARBON	3.3K 5% 1/4W	R1543	1-215-466-00	CARBON	75K 5% 1/6W								
R580	1-247-725-11	CARBON	10K 5% 1/4W	R1544	1-247-885-00	CARBON	180K 5% 1/6W								
R581	1-216-431-11	METAL OXIDE	560 5% 1W	R1545	1-247-874-00	CARBON	62K 5% 1/6W								
R582	1-216-343-00	METAL OXIDE	0.33 5% 1W	R1546	1-215-479-00	CARBON	270K 5% 1/6W								

Ref.No.	Part No.	Description	Remark
C204	1-123-332-00	ELECT 47MF 20% 16V	
C205	1-106-222-00	MYLAR 0.12MF 10% 100V	
C206	1-102-125-00	CERAMIC 0.0047MF 10% 50V	
C207	1-102-125-00	CERAMIC 0.0047MF 10% 50V	
C208	1-106-222-00	MYLAR 0.12MF 10% 100V	
C209	1-123-369-00	ELECT 4.7MF 20% 25V	
C210	1-123-369-00	ELECT 4.7MF 20% 25V	
C211	1-123-369-00	ELECT 4.7MF 20% 25V	
C212	1-123-369-00	ELECT 4.7MF 20% 25V	
C213	1-123-321-00	ELECT 220MF 20% 16V	
C214	1-124-905-11	ELECT 3.3MF 20% 50V	
C215	1-124-905-11	ELECT 3.3MF 20% 50V	
C218	1-123-324-00	ELECT 1000MF 20% 16V	
C219	1-124-445-00	ELECT 100MF 20% 16V	
C221	1-124-925-11	ELECT 2.2MF 20% 50V	
C222	1-123-332-00	ELECT 47MF 20% 16V	
C224	1-124-925-11	ELECT 2.2MF 20% 50V	
C226	1-123-356-00	ELECT 10MF 20% 25V	
C227	1-123-349-00	ELECT 1000MF 20% 35V	
C228	1-108-633-81	MYLAR 0.039MF 10% 100V	
C229	1-124-908-11	ELECT 22MF 20% 25V	
C230	1-106-222-00	MYLAR 0.12MF 10% 100V	
C231	1-123-336-00	ELECT 470MF 20% 25V	
C232	1-108-633-81	MYLAR 0.039MF 10% 100V	
C233	1-124-908-11	ELECT 22MF 20% 25V	
C234	1-106-222-00	MYLAR 0.12MF 10% 100V	
C235	1-123-336-00	ELECT 470MF 20% 25V	
C244	1-123-332-00	ELECT 47MF 20% 16V	
C245	1-124-477-11	ELECT 47MF 20% 25V	
C283	1-123-332-00	ELECT 47MF 20% 16V	

## DIODE

D201	8-719-101-61	DIODE RD6.2E-L2
D202	8-719-101-86	DIODE RD13E-L2
D203	8-719-911-19	DIODE 1SS119
D204	8-719-911-19	DIODE 1SS119
D206	8-719-911-19	DIODE 1SS119

D207	8-719-911-19	DIODE 1SS119
D210	8-719-911-19	DIODE 1SS119
D211	8-719-911-19	DIODE 1SS119
D1519	8-719-110-37	DIODE RD13ES-B3

## IC

IC201	8-759-276-30	IC TA7630P
IC204	8-759-205-84	IC TA7273P

## CONNECTOR

K1	*1-566-054-11	PIN, CONNECTOR 2P
K2	*1-566-056-11	PIN, CONNECTOR 4P
K3	*1-566-057-11	PIN, CONNECTOR 5P
K4	*1-508-765-00	3P PLUG (M)
K5	*1-560-123-00	PLUG, CONNECTOR (2.5MM) 3P

Ref.No.	Part No.	Description	Remark
TRANSISTOR			
Q201	8-729-178-54	TRANSISTOR 2SC2785	
Q207	8-729-177-43	TRANSISTOR 2SD774	
RESISTOR			
R201	1-249-441-11	CARBON 100K 5% 1/6W	
R202	1-249-441-11	CARBON 100K 5% 1/6W	
R203	1-249-419-11	CARBON 1.5K 5% 1/6W	
R204	1-249-429-11	CARBON 10K 5% 1/6W	
R205	1-249-429-11	CARBON 10K 5% 1/6W	
R206	1-249-429-11	CARBON 10K 5% 1/6W	
R207	1-249-419-11	CARBON 1.5K 5% 1/6W	
R208	1-249-419-11	CARBON 1.5K 5% 1/6W	
R209	1-249-432-11	CARBON 18K 5% 1/6W	
R210	1-249-432-11	CARBON 18K 5% 1/6W	
R212	1-249-425-11	CARBON 4.7K 5% 1/6W	
R213	1-249-405-11	CARBON 100 5% 1/6W	
R221	1-215-865-11	METAL OXIDE 220 5% 1W	F
R223	1-247-881-00	CARBON 120K 5% 1/6W	
R224	1-249-412-11	CARBON 390 5% 1/6W	
R226	1-247-881-00	CARBON 120K 5% 1/6W	
R227	1-249-412-11	CARBON 390 5% 1/6W	
R228	1-249-429-11	CARBON 10K 5% 1/6W	
R229	1-249-385-11	CARBON 2.2 5% 1/6W	F
R230	1-249-429-11	CARBON 10K 5% 1/6W	
R231	1-249-385-11	CARBON 2.2 5% 1/6W	F
R236	1-249-423-11	CARBON 3.3K 5% 1/6W	
R243	1-249-417-11	CARBON 1K 5% 1/6W	
R244	1-249-417-11	CARBON 1K 5% 1/6W	
R245	1-249-417-11	CARBON 1K 5% 1/6W	
R246	1-249-417-11	CARBON 1K 5% 1/6W	

\*\*\*\*\*  
\*9-992-308-01 HA BOARD (KEY BOARD UNIT A)  
\*\*\*\*\*

## DIODE

D905	8-719-911-19	DIODE 1SS119
D906	8-719-911-19	DIODE 1SS119
D907	8-719-911-19	DIODE 1SS119
D908	8-719-911-19	DIODE 1SS119
D909	8-719-911-19	DIODE 1SS119

D910	8-719-911-19	DIODE 1SS119
D911	9-990-893-01	LED TLY263P
D912	9-990-893-01	LED TLY263P
D913	9-990-893-01	LED TLY263P
D914	9-990-893-01	LED TLY263P

D915	9-990-893-01	LED TLY263P
D916	9-990-893-01	LED TLY263P
D917	9-990-893-01	LED TLY263P
D918	9-990-893-01	LED TLY263P
D919	9-990-893-01	LED TLY263P

Ref.No.	Part No.	Description	Remark
D920	9-990-893-01	LED TLY263P	
D921	9-990-893-01	LED TLY263P	
D922	9-990-893-01	LED TLY263P	
D923	9-990-893-01	LED TLY263P	
D924	9-990-893-01	LED TLY263P	
D925	9-990-893-01	LED TLY263P	
D926	9-990-893-01	LED TLY263P	
D927	9-990-893-01	LED TLY263P	
D928	9-990-893-01	LED TLY263P	
D929	9-990-893-01	LED TLY263P	
D930	9-990-893-01	LED TLY263P	
D931	9-990-893-01	LED TLY263P	
RESISTOR			
R905	1-247-700-11	CARBON 100 5% 1/4W	
R906	1-247-704-11	CARBON 220 5% 1/4W	
R907	1-247-700-11	CARBON 100 5% 1/4W	
R908	1-247-704-11	CARBON 220 5% 1/4W	
R909	1-247-700-11	CARBON 100 5% 1/4W	
R910	1-247-704-11	CARBON 220 5% 1/4W	
R911	1-247-700-11	CARBON 100 5% 1/4W	
R912	1-247-704-11	CARBON 220 5% 1/4W	
R913	1-247-700-11	CARBON 100 5% 1/4W	
R914	1-247-704-11	CARBON 220 5% 1/4W	
R915	1-247-700-11	CARBON 100 5% 1/4W	
R916	1-247-704-11	CARBON 220 5% 1/4W	
R917	1-247-704-11	CARBON 220 5% 1/4W	
R918	1-247-704-11	CARBON 220 5% 1/4W	
R919	1-247-704-11	CARBON 220 5% 1/4W	

## SWITCH

S905	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)
S906	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)
S907	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)
S908	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)
S909	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)

S910	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)
S911	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)
S912	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)
S913	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)
S914	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)

S915	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)
------	--------------	------------------------------

\*\*\*\*\*

\*9-992-401-01 HB BOARD (KEY BOARD UNIT B)  
\*\*\*\*\*

## DIODE

D940	8-719-911-19	DIODE 1SS119
D941	8-719-911-19	DIODE 1SS119
D942	8-719-911-19	DIODE 1SS119
D943	8-719-911-19	DIODE 1SS119
D944	8-719-911-19	DIODE 1SS119

Ref.No.	Part No.	Description	Remark
D945	8-719-911-19	DIODE 1SS119	
D946	8-719-911-19	DIODE 1SS119	
D947	8-719-911-19	DIODE 1SS119	
D948	9-990-901-01	LED TLS263P	
D949	9-990-901-01	LED TLS263P	
D950	9-990-893-01	LED TLY263P	
D951	9-990-893-01	LED TLY263P	
D952	9-990-893-01	LED TLY263P	
D953	9-990-893-01	LED TLY263P	
D954	9-990-893-01	LED TLY263P	
D955	9-990-893-01	LED TLY263P	
D956	9-990-893-01	LED TLY263P	
D957	9-990-893-01	LED TLY263P	
D958	9-990-893-01	LED TLY263P	
D959	9-990-893-01	LED TLY263P	
D960	9-990-893-01	LED TLY263P	
D961	9-990-893-01	LED TLY263P	
D962	9-990-893-01	LED TLY263P	
D963	9-990-893-01	LED TLY263P	
D964	9-990-893-01	LED TLY263P	
D965	9-990-893-01	LED TLY263P	
D968	9-990-901-01	LED TLS263P	
RESISTOR			
R940	1-247-703-11	CARBON 180 5% 1/4W	
R941	1-247-700-11	CARBON 100 5% 1/4W	
R942	1-247-704-11	CARBON 220 5% 1/4W	
R943	1-247-700-11	CARBON 100 5% 1/4W	
R944	1-247-704-11	CARBON 220 5% 1/4W	
R945	1-247-700-11	CARBON 100 5% 1/4W	
R946	1-247-700-11	CARBON 100 5% 1/4W	
R947	1-247-700-11	CARBON 100 5% 1/4W	
R948	1-247-700-11	CARBON 100 5% 1/4W	
R949	1-247-700-11	CARBON 100 5% 1/4W	
R950	1-247-700-11	CARBON 100 5% 1/4W	
R951	1-247-700-11	CARBON 100 5% 1/4W	
SWITCH			
S940	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)	
S941	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)	
S942	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)	
S943	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)	
S944	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)	
S945	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)	
S946	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)	
S947	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)	
S948	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)	
S949	1-553-766-00	MT SWITCH (KEY BOARD SWITCH)	



N

Ref.No.	Part No.	Description	Remark
---------	----------	-------------	--------

	*9-990-898-01	N BOARD (KEY BOARD UNIT B) *****	
--	---------------	-------------------------------------	--

## IC

IC935	8-741-138-70	IC BX1387 (DETECTOR)	
-------	--------------	----------------------	--

\*\*\*\*\*

## MISCELLANEOUS

\*\*\*\*\*

	△ 1-237-614-11	RESISTOR ASSY, HIGH-VOLTAGE	
	△ 1-426-315-11	COIL, DEMAGNETIZATION	
T604	△ 1-439-372-32	TRANSFORMER ASSY, FLYBACK	
	△ 1-451-295-11	DEFLECTION YOKE (SY-153E)	
	1-452-032-00	MAGNET, DISK; 10MM Ø	
	1-452-094-00	MAGNET, ROTATABLE DISK; 15MM Ø	
	1-452-277-00	MAGNET, BMC	
	1-464-803-11	KEY BOARD UNIT (A)	
	1-464-804-11	KEY BOARD UNIT (B)	
	△ 1-534-820-13	POWER CORD (AEP, AUS ONLY)	
	△ 1-559-409-11	CORD, POWER (WG ONLY)	

S901	△ 1-554-965-12	SWITCH, PUSH (AC POWER)(1 KEY)	
V901	△ 8-736-955-05	PICTURE TUBE (A51JKQ10X)	

\*\*\*\*\*

## ACCESSORIES AND PACKING MATERIALS

\*\*\*\*\*

Part No.	Description	Remark
----------	-------------	--------

A-1470-789-A	COMMANDER ASSY (RM-668)	
*4-377-015-01	BAG, PROTECTION	
*4-382-067-01	CUSHION (UPPER) (ASSY)	
*4-382-068-01	CUSHION (LOWER) (ASSY)	
*4-383-143-01	INDIVIDUAL CARTON	
4-482-400-11	MANUAL, INSTRUCTION	

The components identified by shading and mark △ are critical for safety. Replace only with part number specified.